


REPAIR SHEET

BRAND RYOBI		DESCRIPTION 18 Volt Pruning Shear
MODEL NO. P2505VNM	MFG. NO. 108248012	




TTI OUTDOOR POWER EQUIPMENT, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

1-5-22 (Rev:01)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.






P2505VNM

PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	205843001	Handle Assembly (Inc. Key Nos. 14-18)	1
2	205844001	Circuit Board Assmby	1
3	904118001	Blade Sleeve	1
4	699837001	Spring	1
5	318640001	Trigger and Lock-Out Button Assembly	1
6	210627001	Motor and Gear Box Assembly	1
7	318642001	Knob Assembly	1
8	319129001	Blade Assembly	1
9	545634001	LED Cover	1
10	545635001	Logo Cover	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
11	661205001	Screw (M2.6 x 6 mm, T8 Torx Pan Hd.)	2
12	660173005	Screw (M3 x 5 mm, Hex. Soc. Cap Hd.)	1
13	660203087	Screw (M3 x 12 mm, T10 Torx Pan Hd.)	7
14	941097054	Black Top Label	1
15	941110087	Data Label	1
16	941110089	Icon Label	1
17	941110092	QR Label	1
18	941110088	Warning Label	1
	Not Shown:		
	998000745	Operator's Manual	1



WIRING DIAGRAM