

LEGEND FORCE

QUICK-START INSTRUCTIONS

20" 4 cycle rear tine gear tiller: 1005697759

Before Starting:

IMPORTANT!

- 1. ADD OIL** (included) Oil has been drained for shipping. You **MUST** add oil before starting. Failure to do so will permanently damage your tiller. This tiller requires approximately 0.6 liters of oil.
- 2. ADD FRESH GAS** (If the tiller has been unused for more than 1 or 2 months, drain remaining gas from the tank and fill with fresh gas.

PLEASE ADD TRANSMISSION OIL

This tiller **DOES NOT** come with transmission oil. Please add SAE 85W-140 or 90W-140 transmission oil. Transmission holds 122 to 135 ounces do not overfill oil level.




Please contact our Support Team at 1-877-527-0313 for further assistance.

Fuel On
Move the fuel lever to the "Open" position.



Close Choke
Move the choke lever to the full "Closed" position.




Start Switch
Turn the On/Off switch to the "On" position.



Pull Start
Pull starting rope out rapidly, to start the engine.



Open Choke
When the engine starts, gradually move choke lever to the "Open" position.



NOTE: Restarting an engine that is already warm from previous running does not normally require use of the choke.

