



OMS THD SKU # 1005 273 554

Model # TY401-2017

ASSEMBLY INSTRUCTIONS

6.5 ft 250 Lights LED Potted Tree

USE AND CARE GUIDE

PLANNING ASSEMBLY

Carefully remove all the parts from the box and place them on the ground. Many parts are connected by the lighting string that runs throughout the item. Take special care not to pull, cut or damage the lighting string. Read the entire manual prior to assembly and identify all the parts included in the package against the parts list. It is recommended to assemble parts of the product while laying flat on the ground versus standing the item up to assemble the parts. If any parts are missing or damaged do not attempt assembly but contact our customer service center or return to place of purchase with purchase receipt.

*Assembly of this product may require more than one person.

Pre-Operation

CAUTION: Grasp the plug to insert or remove from the power source. Do not unplug by pulling on cord.

CAUTION: The lighting string on this product is rated at 24 Watts (0.2 Amps). Do not overload. Do not connect to another lighting string, decorative outfit or other electrical products. Before you use or re-use this product inspect it carefully. Discard or return to place of purchase with purchase receipt if the product has cuts, damage, frayed wire insulation on cords, cracks in the socket enclosures, loose connections, exposed copper wire or other obvious damage.

Care and Cleaning

- Carefully remove the product from wherever it is placed. This helps to avoid any undue strain or stress on the product connections and wires. If the product is placed somewhere other than the ground it should be well secured and flat.
- Carefully disassemble the unit taking caution not to cut any electrical wires.
- Wipe the unit with a damp cloth and allow the unit to dry before storing.
- Store the product neatly in a cool, dry location protected from sunlight.

Trouble Shooting

- Ensure that the floor or surface that the item sits on is flat and level
- Be sure to plug the item correctly to a wall outlet or a UL Listed Power Cord
- Ensure all parts are assembled properly per the Instruction Manual
- If the item does not light check for loose or broken bulbs and connections
- Do not plug into other electrical items
- If the item has multiple Light String Cords be sure to plug in all cords
- Check for Broken or Burned Out Fuse In Plug

Guarantee

What is Covered

The product is intended for residential seasonal use for 90 days maximum per year. This product is covered by a 90 days limited guarantee due to defects in material and workmanship. Return the product with purchase receipt to the location of purchase for refund within 90 days of purchase.

What is Not Covered

This warranty does not cover commercial use, normal wear and tear, products not used in accordance with directions provided on or with the product, burn out of bulbs or LEDs, batteries, products that have been subjected to unauthorized repair and/or modification and damage caused by shipping and improper handling, alterations, in-store display models, misuse or accidents. Questions, problems, missing parts? Before returning to the store, call Home Accents Holiday Customer Service 8 a.m.-6 p.m., EST, Monday-Friday



Thank you!

We appreciate the trust and confidence you have placed in Home Accents through the purchase of this 6.5 ft 250 Lights LED Potted Tree. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Accents!

1-877-527-0313

HOMEACCENTSHOLIDAY.COM


| Parts List | | |
|------------|---------------------------------|------|
| Locater | Name | Qty. |
| A | Top section of Tree | 1 |
| B | Middle section of Tree | 1 |
| C | Bottom section of Tree with Pot | 1 |

| Hardware List | | |
|---------------|------------|---|
| D | Spare Fuse | 6 |
| E | Spare Bulb | 6 |


Diagram of Parts



A



B



C

Hardware



D




E

ASSEMBLY


1 Preparing to Assemble the Tree

Choose a place nearby a wall outlet or have an extension cord plugged in and ready to use. Be sure to use a flat, stable surface when in using this product.




2 Assembling the Middle Section to the Bottom Section

Insert the pole of the Middle Section of Tree (B) into the pole of the Bottom Section of Tree (C) then connect the lighting string plugs of the two sections together.



3 Assembling the Top Section to the Middle Section

Insert the pole of the Top Section of Tree (A) into the pole of the Middle Section of Tree (B) then connect the lighting string plugs of the two sections together



4 Final touches for a great look

Shape the tree branches for your desired look then plug the power cord in to an electrical wall outlet or UL extension cord.

