

Installation Guide for Bidet Attachment

Before You Begin

Please read these precautions carefully to ensure safe and successful installation:

1. Turn off the main water supply to your toilet before starting any installation work to avoid water leakage.
2. This ultra-thin bidet attachment (less than 1/4 inch thick) is designed to fit most standard toilets without lifting the toilet seat. Confirm your toilet is a standard size before proceeding.
3. Check all package components to ensure they are complete and undamaged: bidet attachment, stainless steel water connections, mounting hardware, and control knob. Do not use damaged components.

Installation Steps

Step 1: Prepare the Toilet

Clean the area under the toilet seat where the bidet attachment will be mounted. Ensure the surface is dry and free of dirt to secure a stable installation.

Step 2: Disconnect the Water Supply Line

Locate the water supply valve behind the toilet and turn it clockwise to shut off the water. Flush the toilet to empty the tank and relieve any remaining water pressure. Use a wrench (not included) to gently disconnect the water supply line from the bottom of the toilet tank.

Step 3: Install the Stainless Steel Water Connector

Attach the included stainless steel water connector to the bottom of the toilet tank (the same location where you disconnected the water supply line). Tighten it gently by hand first, then use a wrench to secure it firmly—do not over-tighten, as this may damage the seal.

Step 4: Mount the Bidet Attachment

Place the ultra-thin bidet attachment under the toilet seat, aligning it with the toilet's existing mounting holes. Use the included mounting hardware to secure the attachment in place. Ensure it is firm but not overly tight to maintain its low-profile appearance and prevent damage to the toilet or attachment.

Step 5: Connect the Water Supply

Take the included water supply line and attach one end to the bidet attachment's water inlet. Attach the other end to the stainless steel connector you installed in Step 3. Tighten both ends

gently to ensure a leak-proof connection.

Step 6: Test the Installation

Turn the main water supply valve back on by rotating it counterclockwise. Carefully check all connections (toilet tank, bidet inlet, water supply line) and the bidet attachment itself for any leaks. If a leak occurs, gently tighten the corresponding connection until the leak stops.

Post-Installation Note

After confirming no leaks, the bidet attachment is ready for use. For usage instructions, maintenance tips, and troubleshooting, please refer to the product manual.