

## **⚠️ WARNING**

Read and follow all safety instructions prior to using the Tabletop Fire Pit. Severe burn and fire hazard. Failure to follow operating instructions could result in serious injury or death.

Isopropanol Alcohol is highly flammable and dangerous if not handled according to the instructions.

For Outdoor use only.  
For use with 70% or 91% isopropyl rubbing alcohol as fuel source, (not included).

**CAUTION** Never fill beyond fill line on Burn Chamber.

**CAUTION** Cover unit to snuff flame (extinguish flame) before refilling. Use included Snuffing Lid. Never add isopropyl alcohol when lit.

**CAUTION** Flame follows fuel; spilled fuel should be cleaned and dried before lighting Tabletop Fire Pit.

**CAUTION** Hot Surface; do not move or touch while lit or hot. Allow exterior of Tabletop Fire Pit to cool down at least 30 minutes after fire has been extinguished before touching.

**CAUTION** Only use on flat stable surface and never place near flammable objects.

**CAUTION** Only use an extended lighter or long match to ignite Tabletop Fire Pit. Never use a standard lighter or match to activate Tabletop Fire Pit.

**CAUTION** Only use Tabletop Fire Pit on a fire resistant surface, such as stone, metal table, granite countertop, or glass tabletop. Using the Tabletop Fire Pit on a flammable surface can cause fire and lead to serious injury.

**CAUTION** Never refill, move or touch the Tabletop Fire Pit while burning or when hot.

**CAUTION** Do not attempt to blow out flame, only use the included Snuffing Lid to extinguish flame.

**CAUTION** The Tabletop Fire Pit should never be left unattended. Adult supervision is required at all times. Adults must handle, fill, and activate Tabletop Fire Pit.

**CAUTION** Keep out of reach of children and pets.

**CAUTION** Flammable objects must be kept away from Tabletop Fire Pit while lit or hot.

**CAUTION** Keep clothing and hair and hair away from Tabletop Fire Pit when lit. Clothing and hair can catch fire resulting in serious injury.

**CAUTION** Fuel should never be stored or placed near Tabletop Fire Pit.

**CAUTION** Keep fuel in a secure location not accessible by children or pets. Ensure lid is secured to prevent escaping vapors and fuel spills. Fuel spill or vapors can ignite causing fire.

**CAUTION** Do not open fuel container near open fire.

**CAUTION** Discontinue use immediately if cracks appear or fuel or flame show on outside of unit.

**CAUTION** Always empty the Burn Chamber when finished.

**CAUTION** Do not use improper fuels with this Tabletop Fire Pit. Only use 70% or 91% isopropyl alcohol as fuel. Burning wood, pellets, bioethanol, gelled ethanol, paper or other fuel types could cause serious injury or death.

SHARPER IMAGE®

## TABLETOP FIRE PIT



Scan for  
helpful tips and  
instructional  
videos



INSTRUCTION MANUAL

## CONTENTS



TABLETOP FIRE PIT



BURN CHAMBER



SNUFFING LID

## INSTRUCTIONS

Safety should always be the main priority when using the Sharper Image® Tabletop Fire Pit. Read all warnings and safety precautions before proceeding.

### Getting Started:

Place Tabletop Fire Pit on a stable fire resistant surface outdoors.

Fill Burn Chamber with 70% or 91% Isopropyl Alcohol up to the fill line (approx. 1" below the top of Burn Chamber). This will provide approximately 30 minutes of burn time. For shorter burn times use less fuel. (See Diagram A)

Light with a Long Handled Lighter or Match – keep body away while lighting. (See Diagram B)

Once the Tabletop Fire Pit is lit – do not move or touch. Follow all safety precautions and warnings.



### Extinguish Fire:

Place the included Snuffing Lid over the Tabletop Fire Pit. Do not attempt to blow out flame. Allow Snuffing Lid to remain on Tabletop Fire Pit for a minute to ensure flame is completely out. (See Diagram C)



### Refilling:

Ensure flame is completely out. Allow Snuffing Lid to remain on Tabletop Fire Pit for a minute to ensure flame is completely out.

Refill Burn Chamber. 70% or 91% Isopropyl Alcohol up to the fill line (approx. 1" below the top of Burn Chamber) with and light according to instructions above.

CAUTION: The Tabletop Fire Pit will be HOT. Do not move or touch while lit or hot. Allow exterior of Tabletop Fire Pit to cool down at least 30 minutes after fire has been extinguished before touching.



# WARNING

FIRE and EXPLOSION hazard.  
Severe BURNS or DEATH can occur.  
NEVER add fuel to a hot device.

**ALLSTAR**  
INNOVATIONS

©2022 ALLSTAR INNOVATIONS  
DISTRIBUTED BY ALLSTAR INNOVATIONS HAWTHORNE, NY 10532  
PRODUCT COLOR AND APPEARANCE MAY VARY  
MADE IN CHINA

SHARPER IMAGE® NAME AND LOGOS (INCLUDING THE  
77 LOGO AND TOMORROW'S TOMORROW) ARE  
TRADEMARKS OR REGISTERED TRADEMARKS.