10FT. X 10FT. STRAIGHT LEG CANOPY OWNER'S MANUAL





WARNING:

Read carefully and understand all **ASSEMBLY AND OPERATION INSTRUCTIONS** before operating. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury.

Thank you very	much for choosing our product! For future reference, please complete the
owner's record be	elow:
Model:	Purchase Date:
Save the receipt,	warranty and these instructions. It is important that you read the entire manual
to become familia	r with this product before you begin using it.

This canopy is designed for certain applications only. The distributor cannot be responsible for issues arising from modification. We strongly recommend this canopy not be modified and/or used for any application other than that for which it was designed. If you have any questions relative to a particular application, DO NOT use the canopy until you have first contacted the distributor to determine if it can or should be performed on the product.

INTENDED USE

Ideal for backyard parties, camping, tailgating and more.

TECHNICAL SPECIFICATIONS

Item	Description			
Capacity	100 sq. ft. capacity			
Construction	Integrated steel frame (one piece frame)			
Dimensions	10ft. x10ft.			

GENERAL SAFETY RULES

WARNING: Read and understand all instructions. Failure to follow all instructions listed below may result in serious injury.

CAUTION: Do not allow persons to operate or assemble this canopy until they have read this manual and have developed a thorough understanding of how the canopy works.

WARNING: The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions or situations that could occur. It must be understood by the operator that common sense and caution are factors that cannot be built into this product, but must be supplied by the operator.

SAVE THESE INSTRUCTIONS

IMPORTANT SAFETY CONSIDERATIONS

CANOPY USE AND CARE

- WARNING: To avoid personal injury fully read and understand the following instructions before each use. Do not modify the canopy in any way. Unauthorized modification may impair the function and/or safety and could affect the life of the equipment. There are specific applications for which the canopy was designed.
- Always check for damaged or worn out parts before using the canopy. Broken parts will
 affect the canopy operation. Replace or repair damaged or worn parts immediately.
- **Store idle canopy.** When the canopy is not in use, store it in a secure place out of the reach of children. Inspect it for good working condition prior to storage and before re-use.
- Fully read and understand this manual before the assembly of the canopy. Keep this manual with the canopy and accessible for each use.
- Adult assembly only. Do not allow children or people with reduced mental capacity or under the influence of drugs or alcohol to assemble this canopy.
- Low to the moderate wind only. Do not assemble this canopy where it could encounter high winds. There is a danger of it being carried by the wind and it could cause personal injury if it becomes untethered. Ensure the canopy is properly anchored at all times.
- Sunburn Warning. This canopy only provides sun ray protection in the shaded area. Due to the suns position this may not be directly under the canopy. Also, there may be additional sun exposure off of reflective surfaces that cannot be prevented by this canopy. Ensure that users are aware of the sun's position, wear sunscreen, and actively monitor themselves for overexposure to the sun.

WARNING: KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC.
The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.

ASSEMBLY

STEP 1: Verify package contents

Verify package contents by emptying contents of bag(s) and confirming all parts are included and undamaged.

NOTE: Find the stakes in their pocket inside your carry bag. Verify all contents before you set it up.

STEP 2: Pull and extend the frame

- A) Select a smooth, level site for your canopy.
- B) With two people on diagonal corners of the structure, each grab a leg and have one person stand in place while the other walks the frame out. Slide the roof lock mechanisms located on each leg, up toward roof corners, two legs at a time; at each leg, listen for lock to "click" into place. Stop adjusting frame legs at mid-level (half-way mark) for the next step.





STEP 3: Cover the frame with fabric shell

- A) Lay the fabric over the roof.
- B) Line up all corners, adjusting from opposite sides. Fabric will fit snugly.



C) Locate the nylon fasteners on the underside of fabric body, Attach to roof frame.







STEP 4: Extend the legs

Step on frame leg base. Working from opposite sides, slide the roof lock mechanisms (located on upper leg portion) upwards until they lock into place.




TIP: You will hear and feel a click when the roof lock is correctly secured at each position

STEP 5: Stake canopy

- A) Stake canopy by driving stakes through the holes at the foot of each leg. The fabric canopy top also has integrated guy ropes that can be staked as well.
- B) Use additional weights (sand bags, other heavy objects) on each foot or place legs twelve inches down into sand to help secure set up for beach use. Stakes alone will not secure canopy in sand or soft soil.



C) To stabilize the canopy,unroll the guy rope on the corner of the canopy. Tie the other end to the stake and then drive the stake into the ground to secure. (Adjust the stake position to tighten up the guy rope.) Repeat for each guy rope.



DISASSEMBLY

Store all poles and stakes in their corresponding bags to prevent possible tearing or damage to fabric.

STEP 1: Remove the stakes

Carefully remove stakes by pulling out the hook ends.

Remove excess soil from the stakes and store them in their bag.

STEP 2: Take down the canopy

- A) Remove any accessories if installed. Fold for storage.
- B) Press the push button located in the middle of each leg, and carefully lower each leg making sure all legs are level before proceeding. Repeat until frame is lowered to ground.
- C) Remember the fasteners are inside roof line, on side scissors bars, and at corners. Detach all fasteners and remove fabric completely off frame and fold for storing.

NEVER STORE FABRIC ON FRAME. YOU MAY DAMAGE FABRIC, FRAME, OR BOTH.

D) Press the push buttons found on each leg at each upper corner of frame, making sure that all sides are detached from snap button. Slowly slide roof line downward while walking in. This should collapse frame completely.

STEP 3: Store in carry bag


- A) To prolong the life of your canopy, you will want to store it correctly. Please folded frame "feet first" toward carry bag wheels.
- B) Return stakes into their stake bag and place along side frame
- C) Lastly, place folded fabric on top of frame legs, making sure all is completely tucked inside carry bag. Carefully zip carry bag closed.

Note: After fully packing the bag, double check the bag contents and surrounding area for loose parts.

MAINTENANCE

- Maintain your canopy. It is recommended that the general condition of any canopy be examined before it is used. Keep your canopy in good repair by adopting a program of conscientious repair and maintenance. Have necessary repairs made by qualified service personnel.
- **Store idle canopy.** When **canopy** is not in use, store it inside, and in a secure place out of the reach of children. Inspect it for good working condition prior to storage and before re-use.
- Always check of damaged or worn out parts before using the canopy. Broken parts will
 affect the canopy operation. Replace or repair damaged or worn parts immediately.

DIAGRAM AND PARTS LIST



Part#	Description	Qty.	Part#	Description	Qty.
СТОР	Canopy top	1	FPTY	Frame	1
CBAG	Carry bag	1	SSET	Stake	8
GLINE	Guy line	4			

For replacement parts and technical questions, please contact our customer service.