




Function of Grisham Door Cuff Shield

Door Cuff is designed to deter forced access to the interior thumb-turn locking mechanism on your Grisham security door. Door Cuff functions in conjunction with your locked security door and closed entry door, to form a barrier from lock tampering, yet allows for easy access and activation of thumb-turn.



#1. Remove interior thumb-turn faceplate with turn knob



Door Cuff Installation Instructions:

1. Remove thumb-turn faceplate with turn knob.
2. Position Door Cuff over interior surface of security door lockbox in designated location of thumb-turn mechanism.
3. Door Cuff is secured in place with Face plate of thumb-turn mechanism. (No drilling or cutting of Door Cuff required)