

USE AND CARE GUIDE

CLASSIC WOOD SLEIGH QUEEN BED



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-800-986-3460

HOMEDEPOT.COM/HOMEDECORATORS

THANK YOU

Table of Contents

	Tools required
Warranty2	Package Contents
	Assembly
	Maintenance
	Care and Cleaning10
	Troubleshooting10
· iaining / iccomety	

Safety Information



- Keep small parts away from children during assembly.
- □ Read and follow instructions carefully.



- Read these instructions carefully and keep in a safe place.
- TO GUARANTEE THE SAFE USE OF THIS PRODUCT, FOLLOW THE WARNINGS, GUIDELINES AND RECOMMENDATIONS IN THIS MANUAL.
- Adult assembly required.
- Small parts may present choking hazard prior to assembly.



CAUTION

- Do not use power tools to assemble your furniture. Power tools may strip or damage parts/product.
- Do not overtighten connectors (screws, bolts, etc.). Overtightening can lead to product damage.
- Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment. If parts are missing, contact THE HOME DEPOT to obtain any missing parts.
- DO NOT UŠE SUBSTITUTE PARTS.
- This product should only be used on a flat, level surface.
- Assembly requires two people; assembly alone may cause injury.

Warranty

3 YEAR WARRANTY

WHAT IS COVERED

We guarantee this product to be free of manufacturing defects to the original purchaser for three years.

WHAT IS NOT COVERED

This warranty does not cover commercial use, acts of nature, and abusive use.

Pre-Assembly

PLANNING ASSEMBLY

- Use a soft cloth between these parts and the floor.
 Identify the parts which make up your piece of furniture.
 Gather the hardware parts and count them.
 Have the necessary tools ready.
 Keep Allen Key & Wrench as the Bolts & Nuts may need to be tightened in the future.

TOOLS REQUIRED




HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.





Part	Description	Quantity
AA	Head Cap Bolt	6+1
BB	Spring Washer	6+1
CC	Flat Washer	6+1
DD	Allen Key	1
EE	Threaded Rod	10+1
FF	Square Washer	10+1
GG	Nut	10+1
HH	Wrench	1
II	Wood Screw	12+1
JJ	Wooden Dowel	2+1

PACKAGE CONTENTS




Part	Description	Quantity
А	Headboard	1
В	Left Post	1
С	Right Post	1
D	Footboard	1
Е	Side Rail	2
F	Slat	3
G	Center Leg	3

- 1 Attaching Posts to Headboard.

 Attach Threaded Rods (EE) & Wooden Dowel (JJ) to Left & Right Post (B & C).

 Attach Left & Right Post (B & C) to Headboard (A) using Square Washers (FF) & Nuts (GG).


 Tighten Nuts (GG) using Wrench (HH).



- 2 Attaching Head Cap Bolts to unit.


 Attach Head Cap Bolts (AA), Spring Washers (BB) and Flat Washers (CC) to unit.

 Tighten Head Cap Bolts (AA) using Allen Key (DD).



3 Attaching the Threaded Rods


□ Attach Threaded Rods (EE) to Headboard unit and Footboard (D).



- 4 Attaching the Side Rails


 Attach Side Rails (E) to Headboard unit and Footboard (D) using Square Washers (FF) & Nuts (GG).

 Tighten Nuts (GG) using Wrench (HH).



- 5 Attaching Slat & Center Leg to unit.

 □ Attach Center Leg (G) to Slat (F).
 □ Attach Slat (F) to unit using Wood Screw (II).



Maintenance

NEVER

- Allow liquids to remain on furniture. Absorption causes parts to warp and split and finishes to delaminate.
 Use glass cleaner on finished furniture. Ammonia chemically attacks the finish.

- Place in direct sunlight to prevent fading.
 Write directly on surface to prevent marking.
 Place hot objects on surface to prevent finish damage.
 Use rubber based placemats to prevent discoloring.
 Use commercial waxes and polishes to prevent yellowing.


Care and Cleaning

Clean with a soft cloth moistened in lukewarm soap and water. Buff with a dry clean cloth.

Troubleshooting

If the Unit is Not Even With Floor.

Level unit by adjusting the adjustable levelers on bottom of legs.





Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-800-986-3460

HOMEDEPOT.COM/HOMEDECORATORS

Retain this manual for future use