

Palais Royal Collection

Spring kitchen faucet



Installation/Installation/Instalación

CUSTOMER SERVICE

TOLL-FREE 1-877-482-5422

MFF-PRK3-CP - Polished Chrome


MFF-PRK3-BN - PVD Brushed Nickel

MFF-PRK3-ORB - Oil Rubbed Bronze

MFF-PRK3-MB - Matte Black



Tools You Will Need / Outils dont vous aurez besoin / Herramientas necesarias



Adjustable Wrench

Clé à molette

Llave ajustable



Pipe Tape

Ruban pour tuyau

Cinta selladora para rosca

SAFETY TIPS

- If you use soldering for the installation of the faucet, the seats, cartridges and washers will have to be removed before using flame. Otherwise, warranty will be void on those parts.
- Cover your drain to avoid losing parts.
- 0°C~55°C.

CONSIGNES DE SÉCURITÉ

- Si vous posez le robinet par brasage, il est essentiel de retirer les sièges, les cartouches et les rondelles avant d'appliquer la flamme, faute de quoi la garantie sur ces pièces sera annulée.
- Couvrez le drain pour ne pas perdre des pièces.
- 0°C~55°C.

CONSEJOS DE SEGURIDAD

- En el caso de utilizar soldadura para instalar el grifo, remueva los asientos, cartuchos y arandelas antes de usar la llama. De lo contrario, se anulará la garantía para esos componentes.
- Tape la boca del desagüe para prevenir la pérdida de piezas pequeñas.
- 0°C~55°C.

MFF-PRK3-CP
MFF-PRK3-BN
MFF-PRK3-ORB
MFF-PRK3-MB

1a

Install the base and the washer.

1b

Install the 8" base and desk plate.

2

Put the faucet into the mounting hole, and fixed with the fixed assembly.

3

Install the water inlet hoses and tighten with the wrench.

4

Turn on the handle and press the spray head button into the position shown by the arrow to check the operation. This position is for stream function.

5

Press the spray head button into the other position as shown by the arrow to check for the operation. This position is for the spray function.

NO.	Description	Part No.
1	Spring	5T3005600CC/AP/HA/HBW0
2	Hose	5G0024900CP/AP/HA /HBW0
3	Clamping Ring	5M0004500NT0
4	Hand Shower Holder	5N0042800CP/AP/HA/HBW0
5	Retainer Clip	5L0091900PL0
6	Spray Head	5F0007700CP/AP/HA/HBW0
7	O-RING	52008306PL
8	Flange	9Q171400CP
9	Mounting Assembly	53001413PL
10	Flow-Limiting Valve	5X0P0086PL
11	Cartridge	5D0004300PL0
12	Nut	5T1A0003AL
13	Handle	5C0064900CP/AP/HA/HBW0A1
14	Plug & Set-screw	5Y0167400CP0
15	Mounting Hardware	5Q0M0207NT

