

## QO® Load Center Repair / Replacement Parts Single-Phase Fixed Main Lugs

**NOTE:** For specific part numbers, go to [www.schneider-electric.us](http://www.schneider-electric.us), click on Product FAQ's, enter the device catalog number, click SEARCH, then look for the information required. Photos are typical, and may vary slightly from your actual device.

Parts:		
<p>Indoor Cover</p> 	 <p>RB Cover / Door</p> <p>Interior Trim / Dead Front</p>	<p>Interior Assembly</p> 
<p>Indoor Cover Latch Kit</p> 	<p>Indoor Cover Hinges</p> 	<p>Indoor Flush Cover Mounting Screw</p> 
<p>Indoor Surface Cover and RB Interior Trim / Dead Front Mounting Screw</p> 	<p>RB Cover / Door Mounting Screw</p> 	<p>Neutral Bonding Screws (Green)</p> 

Schneider Electric USA  
1601 Mercer Road  
Lexington, KY 40511 USA  
1-888-SquareD (1-888-778-2733)  
[www.us.SquareD.com](http://www.us.SquareD.com)

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

© 2005 Schneider Electric All Rights Reserved