



Industrial Hot Water Nozzle



Threaded Tip, With Protective Cover, For Accessories



CAUTION: Intended for outdoor use only. Severe electrical shock could result if water is sprayed into outlets or sources of electrical current. Do not use water more than 160°F (71° °C).



...don't forget!



Avoid leaks by ensuring the washer is in place before using. If hose washer becomes worn, damaged or lost, replace with a new one.