REPAIR SHEET

BRAND

RYOBI

DESCRIPTION


18 Volt 13 in. Lawn Mower

MODEL NO.

P1108VNM

MFG. NO.

108625001




TTI OUTDOOR POWER EQUIPMENT INC.
P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ **www.ryobitools.com**


5-9-24 (Rev:07)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.

P1108VNM


74
72
33
32
79
76
75
31
25
63
37
30
29
36
83
81
70
35
86
80
92
24
82
84
66
27
54
58
87
88
7
29
60
5
63
26
18
89
68
85
34
14
26
73
13
18
61
14
45
66
61
13
91
66
57
19
55
15
71
91
1
2
69
62
6
3
21
63
66
16
21
22
22
9
65
9
63
12
21
66
23
21
22
10
8
65
8
22
63


P1108VNM


43
48
78
49
77
46
44
47
39
51
51
41
63
49
40
42
40
41
38
42
40
40
20
17
4
61
52
50
11
59
56
53
64
63

PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	205495001	Deck Assembly (Inc. Key Nos. 90-91)	1
2	636503001	Flat Washer	1
3	679075001	Hex Nut (M10)	1
4	698853001	Height Adjustment Rod	1
5	317263001	Rear Door (Inc. Key No. 27)	1
6	636441001	Blade Retainer	1
7	660722002	Screw (M6 x 26 mm, Hex Hd.)	3
8	316712003	6 in. Wheel Assembly	2
9	316713001	7 in. Wheel Assembly	2
10	698849001	Front Wheel Axle	1
11	661431003	Screw (M6 x 14.5 mm, Hex Recess Hd.)	2
12	698851001	Connector Rod	1
13	660727004	Screw (M6 x 70 mm, Hex Hd.)	4
14	698846001	Tube on Deck	2
15	659390001	Height Adjustment Plate	1
16	698850001	Rear Wheel Axle	1
17	664021001	Screw (M3 x 9 mm)	1
18	650027001	E-Ring	2
19	660618007	Screw (#10-14 x .543 in., T25 Torx Hd.)	2
20	542077003	Height Adjustment Knob	1
21	639013001	Flat Washer	4
22	678279004	Cotter Pin	4
23	674178001	Hitch Pin	2
24	742704001	Motor	1
25	311280001	Key Assembly	1
26	542498001	Tube Plug	2
27	941641001	CPSC No Hands Label	1
28	317262001	Top Cover (Inc. Key Nos. 80-89)	1
29	698356001	Battery Door Torsion Spring	1
30	621628001	Battery Door Axle	1
31	679073001	Battery Door Press Spring	1
32	660230013	Screw (M3 x 16 mm, T10 Torx Hd.)	2
33	563768001	Battery Clip Cushion	2
34	291482001	Circuit Board to Terminal Wire (Red)	1
35	660608001	Screw (M4 x 12 mm, T20 Torx Hd.)	2
36	639178001	Key Assembly Female Terminal	2
37	526912001	Key Connector Base	1
38	698848001	Lower Tube	2
39	698847001	Upper Handle Tube	1
40	541821002	Wing Nut with Insert (M6)	4
41	541431001	Cable Clip	2
42	662847001	Shoulder Screw (M6 x 50 mm)	4
43	541873001	Safety Button	1
44	317265001	Trigger Assembly	1
45	700004001	Heat Shrinkable Tube	1
46	292236001	Inner Wire and Plug Assembly	1
47	694991001	Trigger Spring	1
48	699177001	Spring	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
49	317264001	Switch Box (Inc. Key Nos. 77-78)	1
50	541526001	Mulching Plug	1
51	565890001	Foam Tube	2
52	698852001	Grass Bag Frame	1
53	903893003	Grass Bag	1
54	662199001	Screw (M4 x 10 mm, T15 Torx)	2
55	790003001	Cable Tie	2
56	535385001	Trailing Sheet	1
57	870290001	Wire Connector	2
58	661189002	Screw M4 x 10 mm, T20 Torx Pan Hd.)	2
59	541525001	Discharge Baffle	1
60	281161001	Circuit Board	1
61	678460002	Lock Nut (M6)	6
62	682488003	13 in. Blade w/Logo	1
63	661189003	Screw (M4 x 18 mm, T20 Torx Pan Hd.)	33
64	636062001	Flat Washer (OD10 x ID4.5 x 1t)	4
65	639116003	Axle Press Plate	4
66	638557001	Washer (OD15 x ID6.2 x 0.8t)	9
67	541539004	Battery Cover	1
68	622755001	Rear Door Shaft	1
69	528615002	Blade Holder	1
70	680196006	Hex Nut (M6)	3
71	565770001	Height Adjustment Plate	1
72	526979001	Battery Holder	1
73	698961001	Rear Door Torque Spring	1
74	541540001	Handle	1
75	300001067	Contact Plate Holder Assembly	1
76	526978001	Battery Holder	1
77	940705492	Logo Label	1
78	940851634	Instruction/Logo Label	1
79	941016118	Icon Label	1
80	941016114	Danger Label (FR)	1
81	941016115	Danger Label (SP)	1
82	941588756	Data Label	1
83	941016117	Danger Label (ENG) w/Warnings	1
84	940851635	Cut Height Label	1
85	940851636	Start Key Warning Label	1
86	941016119	Wet Conditions Label	1
87	940851637	Side Label (Right)	1
88	940851638	Side Label (Left)	1
89	940851639	RYOBI Logo Label (Front)	1
90	940779341	13 in. Callout Label (Right)	1
91	940779342	13 in. Callout Label (Left)	1
92	940079558	QR Code	1
	Not Shown:		
	998000330	Operator's Manual	




WIRING DIAGRAM

REPAIR SHEET

BRAND	DESCRIPTION
RYOBI	**18 Volt Blower**

MODEL NO.	MFG. NO.
P21011VNM	**108653001**




TECHTRONIC INDUSTRIES POWER EQUIPMENT
P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ **www.ryobitools.com**

10-28-20 (Rev:01)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.

P21011VNM



PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	940705496	Logo Label	1
2	941588776	Icon Label	1
3	941588775	Warning Label	1
4	941588774	Data Label	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
5	542246001	Blower Tube	1
	Not Shown:		
	998000319	Operator's Manual	