



Furniture Care Guide

General Care

Your furniture will maintain its appearance, if you follow this guide.

- Protect your furniture's appearance by avoiding impacts.
- If the furniture has a wall anchor, install it for added safety and stability.
- Do not use furniture outside unless such use is mentioned.
- Avoid injury by sitting or standing on furniture.

Fabric

To remove dirt or light stains from fabric, wipe the surface with a damp microfiber cloth. Air dry before using.

Laminated Surfaces

To remove dirt or light stains, wipe the surface with a damp microfiber cloth. Dry immediately after cleaning.

Metal & Plastic Surfaces

Remove dirt or light stains by wiping the metal and plastic surfaces with a damp microfiber cloth. Air dry before using.

Glass

Remove dirt or liquids by applying a glass cleaner and wiping with a microfiber cloth. Do not use on wood, fabric or laminate surfaces.

© 2020 ATLANTIC INC.
All rights reserved
Customer Service
P.O. Box 2399
Santa Fe Springs, CA 90670