



## 3 TON LOW PROFILE FLOOR JACK WITH SPEEDY LIFT

### Care and Cleaning

---

#### INSPECTION

The product shall be maintained according to these instructions. You may not alter this product in any way.

1. Before using, a thorough inspection shall be made on the jack. Look for cracks in the weld, bent, damaged, loose, worn or missing parts.
2. Inspect according to this manual ONLY.
3. If the jack has been subjected to abnormal load or shock (abuse), perform an immediate inspection. Take the product to a local customer service representative for an authorized inspection before use.

### Maintenance

---

#### CLEANING, MAINTENANCE AND LUBRICATION



**IMPORTANT:** Procedures not specifically explained in this manual must be performed by a qualified technician.



**CAUTION:** To prevent serious injury from tool failure: Do not use damaged equipment. If abnormal noise or vibration occurs, have the problem corrected before further use.

1. Before each use, inspect the general condition of the jack. Check for broken, cracked or bent parts, loose or missing parts, and any condition that may affect the proper operation of the product. If a problem occurs, have the problem corrected before further use.

#### DO NOT USE DAMAGED EQUIPMENT

2. Before each use, thoroughly test the jack for proper operation prior to its actual use. If the jack appears not to be working properly, follow bleeding instructions on page 5.
3. Change the hydraulic oil at least once every three years.
  - A. With the jack fully lowered, remove the Oil Filler Plug on the side of the housing.
  - B. Tip the jack to allow the old hydraulic oil to drain out of the housing completely, and dispose of the old hydraulic fluid in accordance with local regulations.
  - C. With the jack upright, completely fill the housing with a high quality hydraulic oil (not included) until the oil is 1/4" below the fill hole.
  - D. Open the valve by turning the handle counterclockwise and pump the handle to bleed air from the system.
  - E. Recheck oil level and re-fill as needed.
  - F. Reinstall the Oil Filler Plug.

4. Wipe dry with a clean cloth. Then, store the jack in a safe, dry location out of reach of children and other non-authorized people.