

# BAR AND CHAIN COMBINATIONS

**Chain specifications:** 3/8 in. pitch, low profile narrow kerf, .043 in. chain gauge, 5-tooth drive sprocket.

**Length of Bar**  
8 in.

**Guide Bar Part Number**  
316670001

**Chain Part Number**  
682502001

**Drive Links**  
33

## TROUBLESHOOTING

PROBLEM	CAUSE	SOLUTION
Bar and chain running hot and smoking.	Check chain tension for overtightened condition	Tension chain. Refer to <b>Adjusting Chain Tension</b> earlier in this manual.
Motor runs, but chain is not rotating.	Chain tension too tight. Check guide bar and chain assembly. Check guide bar and chain for damage.	Retension chain. Refer to <b>Adjusting Chain Tension</b> earlier in this manual. Refer to <b>Replacing Bar and Chain</b> earlier in this manual. Inspect guide bar and chain for damage.



## CALL US FIRST

For any questions about operating or maintaining your product, call the RYOBI Help Line!

Your product has been fully tested prior to shipment to ensure your complete satisfaction.

**This product has a Three-year Limited Warranty for personal, family, or household use (90 days for business or commercial use).**

**For warranty details, visit [www.ryobitools.com](http://www.ryobitools.com) or call (toll free) 1-800-525-2579.**