ASSEMBLY INSTRUCTION

BS250-257

Ax1



Ex1



STEP1



STEP2



Bx1



Fx4



Cx1



Gx4



STEP3



STEP4



Dx1



PLEASE REMOVE BLACK
CAP FROM
GAS LIFT