Use and Care Manual

Assemble with the upgraded cross-shaped connector (easier than metal clasps), no complex tools needed. Adjust the trellis' height and length based on plant growth needs. Use garden clips, leaf ties, twist tie (66Ft) and trellis netting to secure plant stems gently. The U-frame and arch design ensures stability and maximizes light for plants.
Care: Wipe the plastic-coated steel core trellis regularly to avoid dust. Keep it away from sharp objects to prevent coating damage. Store in a dry place when not in use; it is rustproof, fade-resistant and durable for long-term use.

Replacement Part List

Replace parts with matching specifications for compatibility:

- Cross-Shaped Connectors: Replace if broken or loose to ensure stability.
- Garden Clips (30pcs): Replace lost or damaged clips for securing plants.
- Leaf Ties (100pcs), 66Ft Twist Tie: Replace worn or lost ties.
- Trellis Netting: Replace if torn to support climbing plants.