LR14NT - FRONT LOADING STORAGE RACK



Thank you for choosing Enclume!

Enclume racks are the ultimate quality, design, strength and function.

<u>WARNING</u>: READ ALL OF THE INSTRUCTIONS BEFORE ASSEMBLING AND USING YOUR RACK

If you need help, please call 1-877-ENCLUME

Enclume Design Products

24 Colwell Street, Port Hadlock, WA 98339

Phone 360-385-6100 • Fax 360-385-6156

www.enclume.com


Enclosed you will find everything needed for the assembly and use of your hearth rack. Two people make assembly and installation easier. The parts and hardware included are:

Hardware included:

8 -3/8" x 1/2" Button head Screws
6 -3/8" x 5/8" Button head Screw
4 - Hard Glides
2 - Plastic End Caps
1 – 7/32" Allen Wrench


Components included:

2 - Legs
2 - Leg Supports
2 - Curved Connection Bars
2 - "U" Shaped Body Pieces
2 - Kindling Holders
1 - Tool Bar
1-Broom
1-Shovel
1-Poker



See reverse side for ASSEMBLY AND INSTALLATION INSTRUCTIONS

ASSEMBLY AND INSTALLATION INSTRUCTIONS



Rack Assembly

1) Put together legs, leg supports and hard glides. Use 4-1/2" button head screws.
2) Connect to each other with the curved connectors (curve towards the bottom) placed against the bottom of the leg units. Leave screws finger tight. Use 4 -1/2" button head screws.
3) Place "U" shaped body pieces on top of leg units, aligning holes , screw down finger tight. Use 4-5/8" button head screws.
4) Square - up rack and tighten all screws.
5) Attach kindling holders to the outside of the storage unit. Use 2- 5/8" button head screws.
6) Insert tool bar through the top two loops on the "U" shaped body pieces or the loops on the kindling holders. Push plastic end caps over each end of the tool bar.
7) Hang tools from the tool bar. Your rack is now complete.

WARNING

It is important that your rack is assembled correctly. If the unit is assembled or used incorrectly, it could become unstable and collapse, possibly causing injury.
Natural broom straw is flammable. Keep the broom well away from open flame. It should not be used to sweep hot coals or ash.

Limited Warranty: This product is warranted to be free of material defects for a period of five years from the date of purchase. Customer's exclusive remedy shall be the repair or replacement of the defective product and shall be subject to the following conditions: (1) notice of any defect is received by Enclume within the warranty period and (2) customer returns the defective product to Enclume Design Products, 24 Colwell St., Port Hadlock, WA 98339, *postage prepaid* within *20* days following a return authorization number (which may be obtained by telephoning the number at the top of this instructions) being provided to the customer by Enclume. There are no other warranties, expressed or implied. **THERE ARE NO WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ENCLUME SPECIFICALLY DISCLAIMS ANY AND ALL INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE PURCHASE OR USE OF ENCLUME'S PRODUCTS.**