Easy to Install

Wood walls 

Other walls 



1.Measure and mark target point



2.Drill holes on the wall



3.Mounting brackets



4.Put the curtain onto rod



5.Hang curtain rod



6.Tighten screw to secure rod