Inswinging Latch
DRILL TEMPLATE

For Inswinging Doors Only

1. Fold template on scored line. (This leaf on door).
2. With door in closed position, place fold of template on outside of door against wood stop or metal Z bar, whichever projects farther and spot for holes.
3. Drill three 1/4' holes straight thru door
4. APPLY LATCH TO DOOR IF SPINDLE BIND DUE TO MISALLIGNMENT, ENLARGE CENTER HOLE

4a ,DO NOT OVER TIGHTEN MOUNTING SCREWS SO WILL CAUSE THE ALUMINUM DOOR FRAME TO SQUEEZE ON SPINDLE PREVENTING IT FROM ROTATING THE HANDLE PROPERLY

5. Attach strike to wood jamb with 1-1/4" screws.

