DMX CARPET PAD ™ CARPET UNDERLAYMENT STEP-BY-STEP INSTALLATION CHECKLIST

Prepare the Concrete Floor:

- Ensure the concrete floor is clean, level, and free from dust and debris.
- Inspect for cracks greater than ¼".
- If cracks are found, level the floor using a pre-mixed floor patch.
- Repair any cracks or imperfections and allow them to dry completely.

Install Tack Strips:

- Install tack strips along the perimeter of the room.
- Maintain a small gap (about 1/4" inch) between tack strips to facilitate moisture evaporation.

Lay DMX Carpet Pad:

- Lay DMX Carpet Pad on the concrete floor with the dimple side facing down (Grey side up).
- Place the Carpet Pad against the tack strips.
- Cut the membrane sheets to fit the entire area.
- Repeat the process for the entire installation area.

Roll Out the Carpet:

- Roll out the carpet over the installed DMX Carpet Pad.
- Cut the carpet to fit any adjacent walls or obstacles.

Seal the Carpet Seams:

- Place a section of paper towel on the DMX Carpet Pad to prevent the glue strip from sticking.
- Lay the glue strip on top of the paper towel.
- Position carpet sections on the glue strip.
- Use an iron to melt the glue.
- Press the carpet onto the melted glue strip.

Stretch the Carpet:

- Stretch the carpet over the tack strips for a secure fit.

Job Completion:

- Your carpet installation is now complete!
- If you have any questions, contact our customer support or visit our website for more information.