Scotts®

WHIRL™

HAND-POWERED SPREADER

YEAR-ROUND USE: FEED · SEED · MELT

NO QUIBBLE Scotts® GUARANTEE™ MONEY BACK	ENGINEERED FOR **SMOOTH & EVEN COVERAGE**	**MAXIMUM COMFORT** *WITH* ADJUSTABLE ARM SUPPORT

See back for more details
Para conocer más detalles, consulte el reverso

HOW TO USE:



Know the size of your lawn before you begin. Be sure not to overapply.

Read and follow all directions for use and spreader settings on the label of the product that you are applying.



Set spreader over pavement when filling so any spilled product can be swept up.



Turn the orange dial to correct setting, see settings below.



Begin walking, pull trigger and turn crank clockwise to apply product. Walk at a steady pace (4 ft per second).

SPREADER SETTINGS:

LIGHT		MODERATE		HEAVY
1	2	3	4	5

To increase application rate, adjust spreader setting to a higher number.
Application rates may vary depending on crank and walking speed.

NO QUIBBLE Scotts GUARANTEE™ MONEY BACK

If for any reason you the consumer are not satisfied with the results after using this product, you are entitled to get your money back. Simply send us proof of purchase and we will mail you a refund promptly.
For a complete list of products & settings visit scotts.com, Or call 1-800-543-TURF (8873)

Manufactured by The Scotts Company LLC
14111 Scottslawn Road, Marysville OH 43041
Scotts.com / 1-800-543-8873
© 2025 The Scotts Company LLC. World rights reserved.

LB24644