USE AND CARE FOR POLY RESIN FURNITURE

USE:

- Never place hot items, such as cooking dishes or candles, on poly furniture.
- Remember to clean your furniture—suggested at least once each season (Spring, Summer, Fall, and Winter)
- Avoid placing flowerpots or other items that could stain on poly furniture.
- In severe weather, such as storms containing high winds, hail, or large amounts of snow, it is suggested to cover or store your furniture indoors.

CARE and MAINTENANCE:

- For cleaning, remove any cushions, tablecloths, or other decorative items from your furniture.
- Combine warm water and mild dish soap in a bucket.
- Dip a clean rag into the water-and-soap solution, and gently scrub the surface of the furniture.
- For tough stains, you can try a mixture of 1/3 bleach to 2/3 water. Apply the bleach/water mixture to your poly furniture, then let it sit on the surface of the furniture for a few minutes. You can also use a soft-bristled brush to work the bleach/water mixture into the grooves in the surface or to loosen difficult stains.
- Once you've finished scrubbing, thoroughly rinse the furniture with clean water from a hose or bucket and allow to air dry.