SimplySmartHome

SimplySmart PhotoShare Frame User Guide

V1.4

Table of Contents

Setting up the Frame

1. Plug AC adapter into back of frame, plug into outlet, to turn frame on

2. Choose your timezone. Then press "Next"

3. Pick your WIFI network

4. Enter the WIFI password

5. If there is a firmware update, please choose the update now option

6. Your system will be updated automatically and the frame will restart after the update is completed

7. Install the App (SimplySmart Photoshare) on App Store or Google Play Store

8. Save the Frame ID number, it will be required after you download the SimplySmart Photoshare App

01

Installing the App & Registering an Account

A. For Frame Owner

1. Search "Simplysmart photoshare" in App Store or Google Play Store

2. Launch the Simplysmart photoshare app and select Create New Account

3. Fill in the required fields

4. Check the box after you have read the Privacy Policy and Terms of Service, Then press "Register"

5. Log in

6. Press "Continue"

7. Press "OK" to allow the App to access your photo albums

8. Enter Frame ID provided to you on the Frame screen

9. After the frame is registered, you can begin to send photos from the app to the frame

10. Name your frame

11. Name Success

12. Your will receive an email address for your frame. You and your friends can send photos to the frame by using this email address

13. Now your account is ready to be used

B. For Friends & Family

If you give your frame ID to your friends and family, they can download the app to send photos to your frame

1. Search "Simplysmart photoshare" in App Store or Google Play Store

2. Launch the Simplysmart photoshare app and select Create New Account

3. Fill in the required fields

4. Check the box after you have read the Privacy Policy and Terms of Service, Then press "Register"

5. Log in

6. Press "Continue"

7. Press "OK" to allow the App to access your photo albums

8. Enter Frame ID provided to you on the Frame screen

9. Name your frame

10. Name Success

11. You will have to wait until your request is approved by the frame owner before you can begin to send photos

12. The frame owner will get notified to approve your request

13.When the frame owner approves your request, the frame will turn black indicating that the request has been approved

---

Sending Photos to Frames

A. Using the App

1. Select the frame

2. Select photos to send to frame, then press Send Photos button

3. Sending photos progress screen

4. Photos will show on the selected frame automatically

1. You can send photos to your frame by using your frame email and attaching photos to the email. Photos sent by email must be larger than 400 x 500 pixels

2. If you give your unique frame email to your friends, they can use this email to send photos to your frame. You will receive a notification to approve a request to send photos to your frame
Note: Your frame email can be found in "Settings-Edit Frame"

Sending Photos from the Web Application

A. Sending photos stored on a computer

1. Go to the SimplySmart Home Website - **https://photoshareframe.com**
And log in with your user name and password that you use on your phone App

2. To add photos from your computer, click on **"Add Photos"**

3. Navigate to the location where your photos are stored then select and add the photos to the home page.

4. Select the frames to send photos to. Next, select the photos you wish to send, and then click the **"Send Photos"** button

1. Click on the Facebook icon and log in to your facebook account

2. All your folders and timeline photos will be shown in the App. To send photos to your frame, click on the frame to send photos to and then select the photos to send, and then press the **"Send Photos"** button

3. To return to the home page, click on the home icon.

04

Frame & Friends' management

## A. Edit Your Frame's Name

1. Click the setting icon then select edit frame

2. Select the frame you want to edit, click on "Name"

3. Name your frame and press "OK"

4. Frame name is changed successfully

B. Removing a Frame

1. Click the setting icon then select edit frame

2. Select the frame you want to remove, and press Remove Frame

Note: If you have only one frame (The Master Frame) You will not be able to delete that frame.
To remove the Master Frame, you will have to use the factory reset function in the setting's menu

C. Revoking a permission to send photos

1. To remove a friend's permission to send photos to your frame, go to "Settings-Manage User"

2. Select the friend you want to remove.

3. Select "Delete User & Photos" to remove your friend. Your friend will no longer be able to send photos to your frame

05

SimplySmartHome