成品尺寸 单位(mm)	L	W	H
	60	100	
公差Tolerance	尺寸公差(mm)：±1mm		

80克书纸/单黑印刷 /骑马钉 /尺寸：60X90mm

JisuLife

User Guide
说明书
Bedienungsanleitung
Manuel d'utilisation
Manual
Manual de instrucciones
取扱説明書
دليل

FA42(4500mAh)

English ····· 01-06
Français ····· 07-12
Deutsche ····· 13-18
Español ····· 19-24
Italiano ····· 25-30
Português ····· 31-36
日本語 ····· 37-42
العربية ····· 43-48

Please read this manual carefully before use. Be sure to use the product correctly and safely. Please keep the manual and keep the manual properly for future use.

感谢您购买我们的产品。严格按照说明书要正确使用，并是安全使用。请保存说明书，以便日后参考。

Bitte lesen Sie vor der Verwendung sorgfältig die Anleitung und verwenden Sie das Produkt gemäß den korrekten und sicheren Bedingungen. Bitte bewahren Sie die Anleitung zum späteren Nachschlagen.

Veuillez lire attentivement le manuel avant utilisation et utiliser le produit de manière correcte et sécurisée. Veuillez conserver le manuel pour référence ultérieure.

Si prega di leggere attentamente questo manuale prima di utilizzare il prodotto e di utilizzarlo correttamente e in sicurezza. Si prega di conservare adeguatamente il manuale per riferimento futuro.

Antes de usar, lea cuidadosamente el manual y utilice el producto de forma correcta y segura. Por favor, guarde el manual para futuras consultas.

感谢您购入之相机。请阅读本说明书，以便正确使用。

请妥善保管本说明书，以便日后查阅。

شكرا لشرائك الكاميرا. يرجى قراءة التعليمات بعناية لضمان الاستخدام الصحيح والآمن. يرجى الاحتفاظ بالتعليمات بشكل صحيح للرجوع إليها في وقت لاحق.

FA42(4500mAh)



Appearance Description ····· 07
Precautions Before Use ····· 08
Product Parameter ····· 09
Product Accessories ····· 10
Product Specifications ····· 11
Packing Accessories ····· 12
Description Du Produit ····· 13
Instructions De Mise En Service ····· 14
Précautions Avant Des Utilisation ····· 15
Produktbeschreibung ····· 16
Vorsichtsmaßnahmen Vor Der Verwendung ····· 17
Produktspezifikation ····· 18
Descrizione del prodotto ····· 19
Istruzioni per l'uso ····· 20
Precauzioni prima dell'uso ····· 21
Descripción del producto ····· 22
Instrucciones de uso ····· 23
Precauciones antes del uso ····· 24
Appearance Description ····· 25
Precautions Before Use ····· 26
Product Parameter ····· 27
Product Accessories ····· 28
Product Specifications ····· 29
Packing Accessories ····· 30
Description Du Produit ····· 31
Instructions De Mise En Service ····· 32
Précautions Avant Des Utilisation ····· 33
Produktbeschreibung ····· 34
Vorsichtsmaßnahmen Vor Der Verwendung ····· 35
Produktspezifikation ····· 36
Descrizione del prodotto ····· 37
Istruzioni per l'uso ····· 38
Precauzioni prima dell'uso ····· 39
Descripción del producto ····· 40
Instrucciones de uso ····· 41
Precauciones antes del uso ····· 42
Appearance Description ····· 43
Precautions Before Use ····· 44
Product Parameter ····· 45
Product Accessories ····· 46
Product Specifications ····· 47
Packing Accessories ····· 48

Appearance Description

Precautions Before Use

Please check the product and power cord for any damage and make sure they are in good condition and assemble them correctly before use to prevent injuries or accidents.

2. Before charging the product, please check whether the voltage of the power supply used is consistent with the product rated voltage to avoid damage to the product or electric shock and other accidents, and use the service station designed by the original seller or manufacturer for repair.

A. Switch/Lamp plate

1. When not in use for a prolonged period, please do not use the flash, autofocus, black, fourth, and fifth gears of and power pack off state. Long press one gear to enter the shutdown state.

B. Indicator status description

Indicator status	Meaning
White light always on	Fully charged state
White light flashes slowly	Charging status
The white light flashes once	Gear shift
White light keeps flashing	Battery is too low
White light flashes 3 times	Switch to the next gear

C. Cleaning Products

1. Before cleaning the lens please make sure that the power is off.
2. The product must cannot be removed, and a clean rag and a small amount of water can be used to clean the lens and the rear cover gently when cleaning.
3. Do not use water or other liquids to clean electrical parts, such as the switch and the lens.
4. Do not touch the power supply and electrical components with wet hands or rags.

Battery Use Precautions

Before dismantling the product, the battery must be removed from the product. Pay attention to the presence of hazardous substances in the battery and the battery must be disposed of safely in accordance with the regulations of the place of sale.

产品参数表

参数 Parameter	型号 Model	型号 Model	型号 Model	型号 Model
型号 Model	FA42	FA42	FA42	FA42
电源线 Cable	无	无	无	无
闪光 Flash	无	无	无	无
对焦 Focus	无	无	无	无
黑白 Black and white	无	无	无	无
四挡 Four	无	无	无	无
五挡 Five	无	无	无	无

产品参数表使用说明及注意事项

在公司产品设计和制造过程中，不会有意增加任何有害物质。

但是，由于供应商的原因，可能会有微量成分，被公司产品检测不到。

1. 本公司产品含有的有害物质：

**1、镜面玻璃、镜片、镜面、镜筒、镜头、镜盖、镜筒、镜筒、镜盖、镜盖、镜盖