Wear Safety Goggles
Utilice Gafas Protectoras

EVERBILT™

Magnetic Doorstop with Catch
Tope de Puerta Magnético



English

Designed to keep doors fully open and helps prevent wall damage.

Instructions:

1. Position doorstop in desired location and mark screw holes. Drill 5/32 in pilot holes.
2. Install doorstop in desired location and use appropriate fasteners as required.
3. Position catch on door and mark screw holes. Make sure desired door catch location will match up with doorstop with door fully open.
4. Drill 3/32 in pilot holes.
5. Install and tighten screws.

Español

Diseñado para mantener las puertas completamente abiertas y ayudar a prevenir daños en la pared.

Instrucciones:

1. Coloque el tope para la puerta en la ubicación deseada y marque los orificios para los tornillos. Perfore orficios guía de 5/32 in (4.0 mm).
2. Instale el tope para la puerta en la ubicación deseada y utlice los sujetadores adecuados según se requira.
3. Coloque el protector para puertas en la puerta y marque los orificios para los tornillos. Asegúrese de que la ubicación deseada del protector para puertas coincida con el tope para la puerta cuando la puerta está completamente abierta.
4. Perfore orificios guía de 3/32 in (2.4 mm).
5. Instale y ajuste los tornillos.

MADE IN CHINA
HECHO EN CHINA

Distributed by
Home Depot U.S.A., Inc.
2455 Paces Ferry Rd., N.W.
Atlanta, GA 30339