# Shinco®

# Dehumidifier

MODEL:SDZ1-120P SDZ1-150P

# WIFI OPERATION INSTRUCTION

## WIFI OPERATION INSTRUCTION

### Download and Install APP

Use your phone to scan the QR code below or search **"Smart Life"** in application market to download and install the App.

### Registration

- If you don't have an App account, register an account or sign in with verification code by SMS.This page describes the registration process.
- Tap to enter registration page.
- The system automatically recognizes your country/area. Enter the mobile number/E-mail and tap "Get Verification Code ", as shown in the picture 1.
- If you enter the mobile number, then enter the verification code in the message, as shown in the picture 2, and enter the password to finish your registration.
- If you enter the E-mail, enter the password to finish your registration as shown in the picture 3.

| | | |
|---|---|---|
| **Register**<br><br>Mobile Number/Email<br><br>☐ I Agree Privacy Policy User Agreement<br>Children's Privacy Statement and<br>Third Party Information Sharing List<br><br>Get Verification Code | **Enter Verification Code**<br><br>▯▯▯▯▯<br><br>Verification code has been sent to your mobile phone:<br>XXXX Resend (55s)<br>Didn't get a code? | **Enter Verification Code**<br><br>▯▯▯▯▯<br><br>A verification code has been sent to your email<br>XXXX Resend (57s)<br>Didn't get a code? |
| **Picture 1** | **Picture 2** | **Picture 3** |

## SIGN IN WITH USER NAME AND PASSWORD

The system automatically recognises your country/area. Enter your registered mobile number or Email, and  password to login.

## SIGN IN WITH VERIFICATION CODE VIA SMS

1. Tap "Sign in with SMS verification", to new page.
2. The system automatically recognises your country/area.
3. Enter the mobile number and tap "Get Verification Code " to get a message.
4. Enter the verification code in the message and set password to login the App.

## FORGOT PASSWORD

To find your password back, please follow the procedures:
1. Tap "Forgot password", as shown in the picture 1.
2. The system automatically recognizes your country/area. Enter the mobile number/E-mail and tap "Get Verification Code " to get a message, as shown in the picture 2.
3. Enter the verification code in the message/E-mail, as shown in the picture 3, and enter the new password, tap "DONE" to finish.

---

| | | |
|---|---|---|
| ‹         Register | ‹ | ‹ |
| **Log In** | **Forgot Password** | **Set Password** |
| Please enter your account | Please enter your account | Password |
| Password | | Use 6-20 characters with a mix of letters and numbers |
| | Get Verification Code | Done |
| ☐ I Agree Privacy Policy User Agreement Children's Privacy Statement and Third Party Information Sharing List | | |
| Log In | | |
| **Forgot Password** | | |
| **Picture 1** | **Picture 2** | **Picture 3** |

## CONNECTDEVICE

1. Plug the DEH, the DEH will be in stand by mode. (Do not turn on the unit until the wifi connection is successful.)
2. Press the Humidity setting button for 3 seconds to enter wifi connect mode. (Also use Humidity setting as reset button)
3. Enter the App, tap "+" in the upper right of the page to enter add device page, as shown in the picture.
4. There are two methods to add device: Blink Slowly mode and Blink Quickly mode.
5. Notes: How to set indicator light as Blink Slowly mode and Blink Quickly mode.

Step 1
Plug the unit

Step 2
Hold the reset button for 3s.

Step 3
Confirm indicator light is now blinking quickly.

2 times
per second

Step 4
Hold reset button for 3s until indicator light is blinking slowly

1 time
per 3 seconds

## For Blink Quickly Mode

1. Make sure the device's indicator light blink quickly (2 times per second), tap to go on to the next step (picture 1).
2. Tap to add device as shown in the picture 1.
3. Tap to add the device you need as shown in the picture 2.
4. Select 2.4 GHz Wi-Fi Network and enter password as shown in the picture 3. After entering your password, please tap "Next."

Picture 1

Picture 2

Picture 3

5.Please confirm that the indicator light is blinking quickly(2 times per second), then tap it as shown in picture 4, and select "Blink Quickly" as shown in picture 5.



**Picture 4**



**Picture 5**

6.Picture 6 shows that the device enters the pairing process. During the pairing process, try to make the router, mobile phone and device as close as possible. The normal pairing time is about 20S-40S. And the page after successful pairing is shown in picture 7, select your device to add and you can modify the device name on this page. Then tap "DONE", the device is added successfully.



**Picture 6**



**Picture 7**

7.Please select your device as shown in picture 8, and then enter the product control interface as shown in picture 9.



**Picture 8**



**Picture 9**

## FOR Blink Slowly Mode

1.Please make sure the device's indicator light is blinking slowly (1 time every 3 seconds), then select "Blink Slowly" as shown in picture 1.
2.Connect your mobile phone to the device's hotspot, then go back and add devices as shown in picture 2& picture 3.



**Picture 1**



**Picture 2**



**Picture 3**

**Note: In Blink Slowly Mode, except that the step 5 is different from Blink Quickly Mode, the other steps are all the same.**

**Note:**
If your App interface is shown as picture, it means that the network connection failed.You could try by connecting again or view help.

## 1. CONTROL DEVICE

After successfully configuring the devices, the device will be shown on the home page. Tap to enter its control page.

**Note:**
1. When device is online, it supports short-cut operations.
2.When device is offline, it displays "Offline"and can be controlled.

## 2. CREATE SCENE

Create scene to support the device to perform corresponding actions under various conditions, as shown in the picture.

## Account and Security

" Account and Security" page is for displaying personal account information. You can change login password, binding mobile number, set pattern unlock on this page.

| | |
|---|---|
| **Account and Security** | |
| Region | China |
| Mobile Number XXXX | Linked > |
| Email Address | Link Now |
| Change Login Password | > |
| Face ID | Out of Sync > |
| Pattern Lock | Not Set > |
| Delete Account | > |

## PROFILE-PATTERN UNLOCK

Tap "Pattern unlock" to set your pattern. After setup, you have to enter your pattern to use the App.

Record Pattern Lock

Record Pattern Lock

## FEEDBACK

Entry where users could submit their feedback.

## APP'S OTHER RELATED INFORMATION INCLUDE:

1.Tap on "rate us", App will be redirected to a corresponding App market, where
   you could rate us.
2.Show App version number.

Remark:
1. The pictures used in this wifi section are iOS app interface. Android version is a
   bit different.
2.Product and software update periodically, the number and app interface in this
   manual are only for example. No extra notification on further changes.