2 Pack Shed Windows Installation Guide

Preparation

Ensure the installation area on your shed, trailer, storage room, or other building has a flat, solid surface. Gather basic tools and use the screws included in the package. Check that the 12 x 18 inch window frame (premium aluminum alloy) and components (tempered glass, fiberglass screen mesh) are intact.

Installation Steps

. **Mark the Opening**: Measure and mark a recessed opening matching the window size for flush mount. Ensure it's level to avoid uneven installation.

. **Position the Window**: Place the window into the recessed opening, aligning it evenly with the wall surface to achieve a smooth, flat look.

. **Secure the Frame**: Use the provided screws to fasten the aluminum alloy frame firmly to the wall. Tighten screws evenly to prevent frame distortion.

. **Check Functionality**: Test the sliding mechanism to ensure smooth operation. Verify the tempered glass seals properly and the fiberglass screen mesh is securely attached.