## Care and Maintenance

To clean your filter unit, wipe down the exterior with a damp cloth.

Once filters are at 95% capacity (about every 6 months), the battery alarm will sound and flash red when water is flowing and will continue for 15 seconds once water is turned off. Change the battery every time you replace your filters. The battery is included with the filter replacement cartridges.

## **Pure Satisfaction**

All Aquasana products offer a 90-day 100% satisfaction guarantee. (A 1-year warranty is included, which covers defects in materials and workmanship.) If for any reason you are not satisfied with your purchase, simply call us or the dealer you purchased from. A Return Authorization Code and a full refund will be promptly issued upon return. Thank you for choosing Aquasana!

This filter system is designed and tested for use with genuine Aquasana parts, including replacement filters and all hardware except for the actual faucet. Use of parts from other manufacturers may result in loss of contaminant reduction performance, system damage or failure. Use of parts from other manufacturers (besides the faucet) will also void your warranty. Please visit www.aquasana.com for all replacement parts.

## **Precautions:**

- Aquasana is not liable for consequential or incidental damages due to improper installation.
- Filter is only to be used with cold water.
- If you experience a leak at the hose connection, disconnect and re-seat the hose.

## Model: AQ-5200/5300

Replacement cartridge: AQ-5200R/AQ-5300R

Rated service flow: 0.5 gpm

Max capacity: AQ-5200 500 gal/AQ-5300 600 gal

Min working pressure: 20 psi (1.40 kg/cm²)

Max working pressure: 80 psi (5.62 kg/cm²)

Min operating temperature: 40° F (4.44° C)

Max operating temperature: 90° F (32.22° C)

Do not use with water that is microbiologically unsafe or of unknown water quality without adequate disinfection before or after the system. Systems certified for cyst reduction may be used on disinfected waters that may contain filterable cysts.