

ASSEMBLY INSTRUCTIONS

ITEM NO : EM770FHB/EM970FHB


EM77FFB/EM970FFB

EM770FR/EM970FR

EM770FDB/EM970FDB

DESCRIPTION:BRADEN FULL BOOKCASE STORAGE BED

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.




HARDWARE LIST - 1 (Enclose inside Headboard)				
No	Description	Sketch	Size	Quantity
1	FLAT HEAD CHIPBOARD		M4 x 32mm RBW	8 PCS
2	PAN HEAD CHIPBOARD		M3.5 x 20mm	8 PCS
3	JCBC BOLT		M6 x 35MM BLK	4 PCS
4	JCBC BOLT		M6 x 50MM BLK	2 PCS
5	SPRING WASHER		1/4" Rbw	6 PCS
6	FLAT WASHER		1/4"ID x 13mmODBlk	6 PCS
7	ALLEN KEY		M4x110mm Blk	1 PC

HARDWARE LIST - 2 (Enclose inside Side rail)				
No	Description	Sketch	Size	Quantity
8	FLAT HEAD CHIPBOARD		M4 x 32mm RBW	16 PCS
9	PAN HEAD CHIPBOARD		M3.5 x 20mm	22 PCS
10	JCBC BOLT		M6 x 35MM	15 PCS
11	JCBC BOLT		M6 x 50MM	6 PCS
12	SPRING WASHER		1/4" Rbw	15 PC
13	FLAT WASHER		1/4"ID x 13mmODBlk	15 PCS
14	Z-BRACKET		-	1 PC
15	ALLEN KEY		M4x110mm Blk	1 PC

HARDWARE LIST - 3 (Enclose inside storage drawer)				
No	Description	Sketch	Size	Quantity
16	HANDLE		M4 x 32mm RBW	8 PCS
17	T/HEAD M. SCREW HANDLE		M4 x 48MM	4 PCS
18	T/HEAD M. SCREW HANDLE		M4 x 50MM	4 PCS

TOOLS REQUIRED (NOT PROVIDED)	
Philips screwdriver	
Rubber Mallet	


PART LIST			
NO	DESCRIPTION	SKETCH	QTY
A	Headboard		1 PC
B	Headboard Leg (L/R)		2 PCS
C	Triangle Support Panel -9 x 200 x 200		2 PCS
D	H/board Back Support - 20 x 30 x 1403mm		1 PC
E	H/board Back Support - 20 x 30 x 1403mm		1 PC
F	Footboard		1 PC
G	Drawer Suppt. Rail - 2		4 PCS
H	Side Rail		2 PCS
I	Bed Slat 1387 x 45 x 18mm		3 PCS
J	F/Board Drawer Frame		1 PC
K	Concealed Panel		4 PCS
L	Drawer Suppt. Rail - 1		1 PC
M	Support Leg 1 - 30 x 30 x 518mm		5 PCS
N	Support Leg 2 - 30 x 30 x 95mm		1 PC
O	Support Leg 3 - 30 x 30 x 107mm		1 PC
P	Bed Slat with marking 1387 x 45 x 18mm		2 PCS
Q	Drawer - 1		4 PCS
R	Drawer - 2		2 PCS



MADE IN MALAYSIA


ASSEMBLY INSTRUCTIONS

STEP 1 : Attached and tighten the Headboard Leg L/R (B) to the Headboard (A).Insert Spring Washer (5) Flat Washer (6),use JCBC Bolt (3) to fix with Allen Key (7).




STEP 2 : Attached and tighten the Headboard Leg L/R (B) to the Headboard (A).Insert Spring Washer (5) Flat Washer (6),use JCBC Bolt (4) to fix with Allen Key (7).

STEP 3 : Attached and tighten the Triangle Support Panel (C) to the Headboard and fix the Panhead Screw (2) using Screw Driver.(Not Included)




ASSEMBLY INSTRUCTIONS

STEP 4 : Attach Headboard Back Support (D) and (E) follow the picture. Fix the CSK Screw (1) using a Screw Driver. (Not Included)




STEP 5 : Attach the Side Rail (H) to the Headboard Leg (B) and Footboard (F). Insert Spring Washer (12) , Flat Washer (13), use JCBC Bolt (10) to fix with Allen Key (15).



Fix handle from inside to outside drawer


ASSEMBLY INSTRUCTIONS

STEP 6 : Attach the Footboard Drawer Frame (J) to the Side Rail (H).Insert Spring Washer (12), Flat Washer (13) & JCBC Bolt (10) to fix with Allen Key (15).



STEP 7 : Attach Support Leg 3 (O) to the Footboard Drawer Frame (J).Insert Spring Washer (12), Flat Washer (13) & JCBC Bolt (10) to fix with Allen Key (15).


STEP 8 : Attach the Drawer Support Rail-2 (G) to the Footboard Drawer Frame (J).Insert Spring Washer (12), Flat Washer (13) & JCBC Bolt (10) to fix with Allen Key (15).



STEP 9 : Attach the Drawer Support Rail (G) to the Footboard (F) using CSK Screw (8) and tighten with Screw Driver.(Not Included)


ASSEMBLY INSTRUCTIONS

**STEP 10 : Attach Support Leg 2 (N) to the
Drawer Support Rail-1 (L).Use JCBC
Bolt (11) to fix with Allen Key (15).**



**STEP 11 : Attach Drawer Support Rail-1 (L) to the
Side Rail (H) using Csk Screw (8) and
tighten with Screw Driver.(Not Included)**


**Step 12 : Attach Bed Slat (I) & (P) to the Bed Slat Support (M).
Use JCBC Bolt (11) to fix with Allen Key (15).
(Loosen and tighten the Adjuster to stability of bed)**




**STEP 13 : Attach Z-Bracket (14) to the Bed Slat
Support (M) and Support Leg 2 (N).Use
Panhead Screw (9) and tighten with screw driver (not included)**

ASSEMBLY INSTRUCTIONS


STEP 14 : Attach Drawer-2 (R) on Drawer Support Rail -1 (L).



STEP 15 : Attach Drawer-1 (Q) on Drawer Support Rail -2 (G).



STEP 16 : Install the Handle (16) in front of drawer (R). Tighten the Handle Screw (18) using Screw Driver.(Not Included)



STEP 17 : Install the Handle (16) in front of drawer (Q). Tighten the Handle Screw (17) using Screw Driver.(Not Included)

ASSEMBLY INSTRUCTIONS

STEP 18 : Push the Side Rail (H) with Bed Slat (I) and tighten with CSK Screw (8) by using Screw Driver.(Not Included)
(Make sure follow the center Marking Line as shown)

STEP 20 : Attach Concealed Panel Slat (K) at the Upper Bed Slat (I) using Panhead Screw (9) and tighten with Screw Driver. (Not Included)

