



www.todaysdesignhouse.com

ASSEMBLY INSTRUCTIONS

Wall Cabinets

52124, 562132, 562140, 562157, 562165, 562173, 562181, 562199, 562207, 562215, 562223, 56223 52249, 562256, 562264, 562272, 562282, 562298, 562306, 562314, 562322, 562330, 562348, 56235 51530, 561548, 561555, 561563, 561571, 561589, 561597, 561605, 561613, 561621, 561639, 56164 61654, 561662, 561670, 561688, 561696, 561704, 561712, 561720, 561738, 561746, 561753, 56176





ASSEMBLY INSTRUCTIONS

DHI Corp. • 5205 W. Donges Bay Rd. • Mequon, WI 53092 • 800.558.8700

Unpacking Precautions

Required Tools
Phillips Screwdriver


If using a sharp object to unpack the cabinet components and the packing materials, be careful to avoid scratching or damaging the cabinet components. The various packing materials may be used to protect the cabinet components during assembly. During the unpacking process, place the various components away from and to the side of the work area so that they will not be inadvertently knocked over or otherwise damaged.

Wall Cabinet Model Variations

These assembly instructions include all the steps required to assemble a Wall Cabinet with or without a Shelf/Shelves.




Step 1: Lay the face frame with doors(A) on a soft surface, doors facing down.



Step 2

Attached rubber bumpers to both the top and bottom of each door where they make contact with the face frame to prevent damage and reduce noise.




Step 3

Using the wood glue, squeeze a small bead of glue in all grooves before assembling the cabinet sides, bottom, top and back panels. Be careful not to use too much glue, this could cause access glue to squeeze out and onto the panels, if this should happen, be sure to remove quickly.


Step 4

Slide the left and right side panels into the Left grooves of the face frame, and mount the male clip to the face frame with a screwdriver. Each male clip will need 2 Small screws (I).



Step 5


Slide the top(T) and bottom panel(B) into the grooves of the right and left side panels, and then into the groove in the frame below until it is fully seated.



The two optional hanging bars are included. These are to be installed at the top and bottom of the inside of the cabinet prior to mount to the wall. The Larger screws(M 2 3/8") are needed.


Step 6

Insert the Back panel between the two Side Panels.



Step 7

Use the long screws(K), and the pre-drilled holes, to attach the back panel to the edges of the bottom panel.



Step 8

Put the shelf pins on the left and right side panels using the holes provided. Be sure the pegs on the right & left are in the same position on each side to insure a level fit.

