



Tools you will Need


Tool Checklist.




☐ Phillips/Flathead
Screwdriver




☐ Power Drill



☐ Hammer



☐ Level




☐ Towel Bar

Install the Towel Bar


Follow these steps for installation.

1.




Using a level and measuring tape, measure the distance between mounting plates. Mark screw points with tip of screwdriver or pencil.

2.




Prepare fastener holes for attaching the mounting plates using options below:
A. Attaching to stud in drywall.
B. Attaching to drywall.

2a.




Attaching to stud in drywall:
Use drill bit smaller than the screws to pre-drill holes.

2b.




Attaching to drywall:
Use drill size appropriate for wall anchors. Tap each anchor in wall with hammer.

3.




Attach each mounting plate to wall by installing screws into pre-drilled wall anchor holes.

4.



Assemble the towel bar and attach the towel bar ends to the mounting plates. Push the ends into the wall and then downward, securing the towel bar.

5.



The towel bar is now securely in place.

Important: Please use the provided beige wall anchors for drywall-only installation. To use, follow the above-referenced steps, but concurrently screw in both screw and beige wall anchor into wall.

For installation on tile surface/wall, please seek professional assistance at your local hardware store or consult a licensed contractor. Please note tile installation requires a tile drill bit.