
# USE AND CARE GUIDE

## 5 IN. x 2 IN. CASTER SET

Questions, problems, missing parts? Before returning to the store, call Husky Customer Service 8 a.m. - 5 p.m., EST, Monday - Friday

1-888-HD-HUSKY

WWW.HUSKYTOOLS.COM



Due to continuing improvements, the actual product may differ slightly from the product described herein.

#### THANK YOU

We appreciate the trust and confidence you have placed in Husky through the purchase of this caster set. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs.

Thank you for choosing Husky!

#### Table of Contents

Table of Contents   2     Safety Information   2	
Warranty	
Specifications 2	Service Parts
Pre-Installation2	

## Safety Information

To reduce the risk of serious injury, read and follow the safety instructions below before assembling and using this product.

- This product is intended for indoor use only.
- This product is not designed for commercial nor industrial usage.



CAUTION: This caster set is for Husky 28 in. 4-drawer base cabinet and Husky 28 in. 2-door base cabinet only.



CAUTION: Check all nuts and bolts periodically for tightness. When required, tighten them again.



WARNING: Any assembly or maintenance of the product must be carried out by adults only.



WARNING: Wear safety glasses when removing or repositioning the casters. The tool could slip, causing personal injury.



CAUTION: DO NOT move the base cabinet when the caster are braked. DO NOT use casters on rough or uneven surface.



CAUTION: DO NOT over load. This may cause caster to collapse and /or base cabinet to tip over with serious personal injury, or product damage.

## Warranty

3 year Limited Warranty. This warranty excludes incidental/inconsequential damages and failures due to misuse, abuse or normal wear and tear. This full warranty gives you specific rights, and you may also have other rights, which vary state to state. Contact the customer service team at 1-888-HD-HUSKY or visit www.huskytools.com.

## **Specifications**

Maximum load for caon caster 220 pg. / 100 kg	Maximum load for each caster	220 lbs. / 100 kg
---	------------------------------	-------------------

#### Pre-Installation

#### TOOLS REQUIRED



Phillips

Screwdriver



(not included)

Safety Goggles (not included)



Open End Wrench (10mm)(not included)

#### HARDWARE INCLUDED






Part	Description	Quantity
AA	M6 x 16 hex flange bolt	16

## Pre-Installation (continued)

#### **PACKAGE CONTENTS**






Part	Description	Quantity
Α	Swivel caster	2
В	Rigid caster	2

## Assembly



Make sure the brakes of the rigid casters face towards the inside of the base cabinet.

- Carefully lay the base cabinet on its back, with a soft mat underneath for protection.
- Position the two swivel casters (A) on the back side of the base cabinet. Insert eight M6 x 16 hex flange bolts (AA) through the casters and into the bottom of the base cabinet. Tighten securely.
- Repeat the same procedure to install the two rigid casters (B) on the front side of the base cabinet.
   The brakes of the rigid casters (B) should face towards the inside of the base cabinet.




### **Maintenance**

Check all the bolts and nuts periodically for tightness. Tighten them when necessary.

## Care and Cleaning

- Clean the caster surfaces periodically with a soft rag and water.
- Grease and oil can be removed with most standard cleaning fluids.
   For safety, use a nonflammable cleaning fluid.

## **Service Parts**



Part	Replacement Part #	Description	Quantity
Α	302201	Swivel caster	2
В	302200	Rigid caster	2
AA	321006	M6 x 16 hex flange bolt	16



Questions, problems, missing parts? Before returning to the store, call Husky Customer Service 8 a.m.-5 p.m., EST, Monday-Friday

1-888-HD-HUSKY

WWW.HUSKYTOOLS.COM

Retain this manual for future use.