

Assembly instructions for CAMERON NIGHT STAND CM750NS

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PART LIST			
NO.	PARTS DESC	CODE	Q'TY
A	NIGHTSTAND		1
B	FRONT LEGS	PCM950BFFL	2
C	BACK RIGHT LEG	PCM950BFBR	1
D	BACK LEFT LEG	PCM950BFBL	1

HARDWARE LIST			
NO.	HARDWARE DESC	CODE	Q'TY
1	 Flat Washer (Ø5/16"*19*2mm)	PCM750 LHW	8
2	 Spring Washer(Ø5/16")		8
3	 Bolt (Ø5/16"*50mm)		8
4	 Allen Key M4		1

