

WARNING

TIP-OVER HAZARD

Use two or more people to move and install the refrigerator. To prevent the refrigerator from tipping over, install anti-tip brackets (provided). Failure to follow the refrigerator installation instructions can result in serious injury or death.



ENGLISH

WARNING

To reduce the risk of fire, electric shock, or personal injury when using your product, basic safety precautions should be followed, including the following. Read all instructions before using this appliance.

1. When Connecting the Power

This appliance incorporates an earth connection for functional purposes only.

Use a dedicated outlet.

- Using several devices at one outlet may cause a fire.

Plug in the power plug with the power cord facing downward.

Failure to do so could damage the plug or cord, resulting in fire or electric shock.

When moving the refrigerator away from the wall, be careful not to roll over or damage the power cord. Do not squeeze or crush the cord or plug when pushing the refrigerator back in.

Doing so could result in fire or electric shock.

Do not allow the power cord to be bent, crushed, or damaged. Do not run the power cord under heavy objects like furniture, other appliances, or through high-traffic areas.

Doing so may damage the power cord and result in fire or electric shock.

Do not extend or modify the length of the power cord.

Use only an exact factory replacement part to avoid electrical issues, fire, or electric shock.

Unplug the power cord or turn off the power when cleaning or moving the refrigerator.

- Failure to do so may cause electric shock or injury.
- Press the POWER button for 3 seconds to turn off the power at display panel.

Do not pull out the cord or touch the power plug with wet hands.

Doing so may cause electric shock or injury.

Remove water or dust from the power plug and insert it securely into the wall socket.

Dust, water, or a loose connection may cause a fire or electric shock.

Do not unplug the refrigerator by pulling on the cord.

Doing so may cause electric shock or short circuit resulting in a fire.

Do not use the power cord or the power plug if it is damaged or if the outlet is damaged.

Doing so may cause electric shock or short circuit resulting in a fire.

Wait for 5 minutes or longer when reconnecting the plug.

Give the compressor time to cycle before re-starting.

If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.

An individual properly grounded branch circuit or circuit breaker must be used in case of requiring disconnect after installation.

2. When Using the Refrigerator

Do not place heavy or dangerous objects on the refrigerator.

Opening or closing the door may cause objects to fall, resulting in injury, fire, or electric shock.

Do not install the refrigerator in a damp location or where it will be exposed to running water.

Deterioration of the insulation on electrical parts may result, causing risk of electric shock.

Do not allow children to hang on the refrigerator doors, shelves or drawers.

Doing so may cause serious injury.

Do not allow children to climb into the product.

A child's life could be endangered if the child climbs into the refrigerator.

Opening and closing the door of the refrigerator vigorously may cause the stored food in the door bins to fall.

Do not use or store flammable materials like ether, benzene, alcohol, medicine, LP gas, sprays, or cosmetics near or in the refrigerator.

Doing so may cause explosion or fire.

Do not use a hair drier to dry the inside, nor light a candle to remove odor.

Doing so may cause explosion or fire.

The automatic defrosting system in the appliance ensures that the compartment remains free of ice buildup under normal operating conditions.

Note that a temperature rise after defrosting has a permissible range in the appliance specifications. If you wish to minimize the impact this may have on the food storage due to a temperature rise, seal or wrap the stored food in several layers.

Do not use combustible sprays (including cooking sprays, oils and other aerosol products) on or near the refrigerator.

Doing so may cause a fire.

Do not install the refrigerator near a gas stove, water heater or other source of ignition that may possibly leak gas.

Turn off the refrigerator if you will not be using it for an extended period of time, or in the event of a severe electrical storm.

Press the POWER button for 3 seconds to turn off the power at the control panel.

If your refrigerator is leaking, have it checked by an authorized service technician before operating it.

Failure to follow this warning may cause electric shock or fire.

Do not spray water inside or outside the refrigerator, do not clean it with benzene or thinner.

If the insulation around electrical parts deteriorates, it can result in electric shock or fire.

If a strange smell or smoke is detected from the refrigerator, turn off the refrigerator and contact the service center.

Failure to follow this warning may result in a fire.

Do not allow any person except an authorized servicer to disassemble, repair, or alter the refrigerator.

Doing so may cause injury, electric shock or fire.

This product is not to be used for special purposes such as the storage of medicine or test materials or for use on ships, vehicles, aircraft, etc.

Doing so may cause an unexpected risk such as fire, electric shock, deterioration of stored material, chemical reaction.

When discarding the appliance, remove the door gasket while leaving the shelves and baskets in place, and keep children away from the appliance.

Child entrapment generally results in death by suffocation.

This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

Install the refrigerator on a solid and level floor.

If the refrigerator tips when opening or closing the door, it could fall over, causing property damage and personal injury.

Do not put hands, feet, or metal objects into the air vents or cover, or below or behind the refrigerator.

Doing so may result in electric shock or injury.

Do not step on the pipe under the freezer door.

Doing so may cause electric shock or injury.

Connect to potable water supply only.

Non-potable water can cause health risks.

If connected to a circuit protected by fuses, use time delay fuse.**Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.****Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.****Do not damage the refrigerant circuit.****Do not use electrical appliances inside the refrigerator.****If disposing of a refrigerator, make sure the refrigerant is removed for proper disposal by a qualified servicer. If you release the refrigerant, you may be fined or imprisoned in accordance with the relevant environmental law.****Risk of Fire and Flammable Materials**

This appliance contains a small amount of isobutane refrigerant (R600a), which is combustible. When transporting and installing the appliance, care should be taken to ensure that no parts of the refrigerating circuit are damaged. Refrigerant squirting out of the pipes could ignite or cause an eye injury. If a leak is detected, avoid any naked flames or potential sources of ignition and air the room in which the appliance is standing for several minutes.

In order to avoid the creation of a flammable gas air mixture if a leak in the refrigerating circuit occurs, the size of the room in which the appliance may be sited depends on the amount of refrigerant used. The room must be 10.8 square feet (1 square meter) in size for every 8g of R600a refrigerant inside the appliance. The amount of refrigerant in your particular appliance is shown on the identification plate inside the appliance. Never start up an appliance showing any signs of damage. If in doubt, consult your dealer.

CAUTION

Do not insert hands into the ice bucket or the ice dispenser.

Doing so may cause injury.

Do not touch food or containers in the freezer with wet hands.

Doing so may cause frostbite.

Do not put ice in a thin crystal cup or ceramic ware.

The glass may shatter and present a hazard.

If power goes out, remove ice from ice bin.

Ice will melt and water will leak onto floor. Dump ice if power is out for a long period.

Do not remove the cover of the automatic ice dispenser.

The internal mechanism of the icemaker can cause injury if handled.

Place food items and containers carefully on the shelves in the refrigerator.

Opening and closing the door may cause food to fall, resulting in injury.

Do not put glass bottles or containers in the freezer.

Contents may break the bottle when frozen, causing risk of injury.

Do not stick your hands under the refrigerator.

Sharp edges, fans, and wires may cause an injury.

Close the door carefully when children are near.


Keep fingers out of pinch point areas; clearances between the doors and cabinets are necessarily small.

Do not put live animals into the refrigerator.

ENGLISH

SAVE THESE INSTRUCTIONS

Product Overview



Product Specifications

The appearance and specifications listed in this manual may vary due to constant product improvements.

Electrical requirements: 115 V, 60 Hz

Min. / Max. water pressure: 20 - 120 psi (138 - 827 kPa)

Model SRSXB2622*	
Description	Built-in, Refrigerator
Net weight	542 lb (246 kg)

Starting

When the refrigerator is first installed, allow it to stabilize at normal operating temperatures for 2-3 hours prior to filling it with fresh or frozen foods. If operation is interrupted, wait 5 minutes before restarting.

Adjusting the Temperatures and Functions

