

1.Assembly Instructions

Tools Required:

Wrench

Screwdriver

Pliers

Ladder (optional for installation height)

Parts Included:

1 Saucer Swing Seat

2 Heavy-Duty Chains

1 Adjustable Strap

4 Metal Tubes (for the frame)

4 Bolts and Nuts

2 U-shaped Hooks

1 Safety Carabiner

Instruction Manual (this guide)

Step-by-Step Assembly:

2.Frame Assembly:

Lay out the metal tubes on the ground in front of you.

Insert the tubes together, aligning the connectors on the ends.

Use the bolts and nuts to secure the tubes together into a circular frame. Tighten each connection to ensure stability.

Attaching the Saucer Seat:

Take the saucer seat and locate the loops on the sides of the seat.

Attach the heavy-duty chains to the loops of the saucer seat using the U-shaped hooks.

Ensure they are securely fastened.

Attach the other end of the chains to the adjustable strap (for height adjustment). Ensure the carabiner is tightly fastened to the chains and the frame.

Securing the Swing:

Use a ladder if necessary to reach the top of the swing frame.

Find the attachment points on the swing frame and attach the free ends of the chains using the carabiner.

Double-check that all connections are secure and properly tightened to prevent accidents.

Final Check:

Ensure the swing seat is level and that the chains are not twisted.

Check for any loose bolts or hardware, and tighten as needed.

Test the swing gently with a light load before use.

3. Safety Guidelines

Weight Capacity: The swing has a maximum weight capacity of 440 lbs. Ensure that the combined weight of all users does not exceed this limit.

Supervision: Always supervise children when using the swing.

Installation Area: Make sure the swing is installed in a clear, open area free from obstacles like trees, fences, or hard surfaces. The minimum clearance is 6 ft. from any obstruction.

Grounding: Ensure that the ground under the swing is soft (e.g., grass or rubber mats) to prevent injury in case of a fall.

Check for Damage: Inspect the swing regularly for signs of wear and tear. Replace any damaged parts immediately.

Weather Conditions: This swing is designed for outdoor use but should be stored in a sheltered place during extreme weather (e.g., heavy storms or high winds) to prevent damage.

Swinging Limits: Do not allow the swing to swing too high or too fast. Only use it as designed.

4. How to Use the Swing

Getting on the Swing: Carefully sit in the center of the saucer swing. For added safety, ensure that you are seated properly with your legs positioned around the edge.

Swinging: Gently push off the ground with your feet or ask someone to push you to start swinging. Avoid swinging too high to ensure safety.

Dismounting: When stopping, gradually slow the swing down and safely step off the swing.

Adjusting the Height: Use the adjustable strap to modify the height of the swing for different users. Simply adjust the length of the strap to the desired height, ensuring it is secure before use.

5. Care and Maintenance Tips

Cleaning the Swing:

Regularly wipe down the saucer seat and frame with a damp cloth to remove dust and debris.

For tougher stains, use a mild soap solution and a soft brush.

Do not use harsh chemicals or abrasive materials that can damage the material or finish.

Chain and Strap Care:

Inspect the chains for any signs of wear or rust. If any rust is visible, clean it off with a wire brush and apply a rust-resistant spray.

Ensure the adjustable strap is not frayed or damaged. If damaged, replace it immediately to ensure safety.

Storage:

If not in use for an extended period, disassemble and store the swing in a dry, sheltered area to prevent exposure to harsh weather conditions.

For prolonged storage during winter or rainy seasons, it is recommended to cover the swing with a weather-resistant tarp.