



MAGIC CHEF®

COOKING FUNCTIONS CHEAT SHEET - READ ME FIRST!

Copyright © 2019 MC Appliance Corp. All rights reserved.

PROGRAM	MODE	WHAT DO I COOK ON THIS MODE?	COOK TIME
Pressure Cook	Less		20m
	Normal	Choose your own cook time using the up and down buttons.	35m
	More		45m
Soup Broth	Less	Veggie soup.	20m
	Normal	Soup with meats and/or grains.	30m
	More	Homemade chicken stock! Fill up the pot with chicken bones and leftover veggie scraps, then fill to the Max Fill line with water.	4H
Meat Stew	Less	Cooks cubed meat to just tender.	20m
	Normal	Cooks cubed meat to falling apart.	35m
	More	Cooks larger cuts of meat to tender.	45m
Bean Chili	Less	Pre-soaked beans.	20m
	Normal	Ground meat chili.	30m
	More	Beans that weren't pre-soaked.	45m
Rice	Less	White rice. Time includes the pressure to release naturally for 10 minutes.	13m
	Normal	Brown rice. Time includes the pressure to release naturally for 5 minutes.	20m
	More	Wild rice. Time includes the pressure to release naturally for 10 minutes.	40m

PROGRAM	MODE	WHAT DO I COOK ON THIS MODE?	COOK TIME
Multigrain	Less	Very tender brown rice.	20m
	Normal	Very tender wild rice.	40m
	More	Very large beans, cooked tender.	1H
Oatmeal	Less	Quick cooking oats.	3m
	Normal	Super soft steel cut oats.	12m
	More	Congee.	30m
Slow Cook	Less	Shredded chicken.	4H
	Normal	Shredded pork.	6H
	More	Shredded beef.	8H
Cake	Less	Brownies and box cakes.	30m
	Normal	Perfectly tender cheesecake, everytime.	40m
	More	Denser cheesecake.	50m
Yogurt	Less		24H
	Normal	See manual to learn how to make yogurt using your MultiCooker.	8H
	More		Boil
Steam Egg	Less	Large cuts of vegetables like carrots and broccoli. Hard boiled eggs, with a ten minute natural release.	3m
	Normal	Thick cuts of fish, like swordfish or tuna.	10m
	More	Frittata.	15m