

Use and Care Manual

Use Instructions

- **Weight Limit:** Do not exceed the maximum weight capacity of the swing (typically 500–600 lbs / 227–272 kg). Do not allow more than two adults to sit on the swing at the same time.
- **Swinging Motion:** Gently push the swing to start the motion. Avoid excessive force or sudden, jerky movements that could damage the frame or suspension ropes.
- **Placement:** The swing is designed for indoor or covered outdoor use. Ensure the ceiling support is sturdy enough to handle the weight and movement. Avoid using it in areas with low ceilings or overhead obstacles.
- **Comfort Adjustment:** Adjust the position of the throw pillows for optimal comfort.

Care Instructions

- **Cleaning:**
 - Remove the seat cushion and throw pillows from the frame. Hand-wash with mild detergent and cold water. Avoid bleach or harsh chemicals. Air dry completely before reattaching.
 - Wipe the wooden frame with a soft, damp cloth and mild detergent. Avoid abrasive cleaners that may scratch the finish.
 - Clean the suspension ropes with a damp cloth to remove dirt and debris.
- **Maintenance:**
 - Regularly check all knots, fasteners, and ceiling mounts for tightness. Retighten as needed to maintain stability.
 - Inspect the wooden frame for signs of splintering, cracking, or rot. Replace any damaged components as needed.
 - Inspect the suspension ropes for signs of fraying or wear. Replace if any damage is found.
- **Storage:**
 - If storing the swing for an extended period, disassemble it and store the components in a cool, dry place away from direct sunlight and moisture.
 - Cover the swing with a waterproof cover when not in use to protect it from the elements.
- **Safety Notes:**
 - Do not allow children to use the swing without adult supervision.
 - Keep loose clothing, hair, and fingers away from the suspension ropes and frame to avoid injury.
 - Do not use the swing as a ladder or for any purpose other than its intended use as a hanging swing bed.