

Cleaning and Maintenance

CLEANING

Outside/Exterior

- Wipe with a clean cloth lightly dampened with appliance polish wax or mild liquid dishwashing detergent. Dry and polish with a clean, soft cloth.
- Do not wipe the glass door freezer with a soiled dishwashing cloth or wet towel. Do not use scouring pads, powdered cleaners, bleach, or cleaners containing bleach.

Inside

- Use warm water and baking soda solution—about a tablespoon of baking soda to a quart of water. Rinse thoroughly with water and wipe dry.
- Do not use cleaning powders or other abrasive cleaners. An open box of baking soda in the glass door freezer will absorb stale freezer odors. Change the box every three months.
- An open box of baking soda in the freezer will absorb stale freezer odors. Change the box every three months.

PROLONGED OFF PERIODS

If the glass door freezer is not to be used for a long period of time, disconnect glass door freezer from main power supply. Clean and dry the inside as instructed. Leave the freezer door open to prevent any mold and mildew growth.

Usage Tips:

- Keep the freezer's door closed as much as possible. Try not to open the door too frequently, especially when weather is hot and humid.
- Ensure that the unit has sufficient clearance for ventilation.
- For normal household use, it is recommended to set the temperature in the middle setting.
- Before loading the glass door freezer with an item, make sure they are cooled to ambient temperature.
- Ice and frost layer increase energy consumption, defrost when frost is 3-5 mm thick.

PREPARING FOR VACATION

To maintain glass door freezer in operation during vacations, be sure your house power is not turned off. For extended vacations or absences, you may prefer to move your frozen foods to a storage locker temporarily. If your glass door freezer is to be left empty, disconnect power cord plug from power source. To prevent formation of odors, place open box of baking soda in glass door freezer and leave glass door freezer door open.

POWER INTERRUPTIONS

If the electricity goes off for a short period, keep the door closed to help food stay cold and frozen. If the power will be out for a longer period of time, remove food from the appliance and store it in a frozen food locker.

NOTE: If the appliance is unplugged, encounters a power interruption, or is turned off, you must wait 3 -5 minutes before restarting the appliance. If attempted to restart before this time delay, the appliance may not start.

IN CASE OF EXTENDED POWER FAILURE

- Keep freezer door closed. Your freezer will keep food frozen for 24 hours provided warm air is not admitted.
- If freezer is out of operation for 24 hours or more, add dry ice. Leave ice in large pieces. Add more ice as required.
- If dry ice is not available, move food to frozen locker temporarily—until power is restored.

NOTE: Handling of dry ice can cause freezing of the hands—gloves or other protection is recommended.

ENERGY SAVING TIPS

The glass door freezer should be located in the coolest area of the room, away from heat-producing appliances or heating ducts, and out of direct sunlight. Let hot foods cool to room temperature before placing in the glass door freezer. Overloading the glass door freezer forces the compressor to run longer. Foods that freeze too slowly may lose quality or spoil. Be sure to wrap foods properly, and wipe containers dry before placing them in the glass door freezer. This cuts down on frost buildup inside the glass door freezer.

Freezer shelves should not be lined with aluminum foil, wax paper or paper toweling. Liners interfere with cold air circulation, making the glass door freezer less efficient. Organize and label food to reduce door openings and extended searches. Remove as many items as needed at one time, and close the door as soon as possible.