


USE AND CARE GUIDE

LAGUNA POINT 4 PIECE SET WITH CUSHIONS



Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this 4 piece set. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

| | | | |
|---------------------------|---|--------------------------------|----------|
| Table of Contents | 2 | Pre-Assembly | 3 |
| Safety Information | 2 | Hardware Included | 3 |
| What is covered. | 3 | Package Contents | 4,6,8 |
| What is not covered. | 3 | Assembly | 5,7,9,10 |
| Warranty | 3 | Cleaning and Maintenance | 11 |
| | | Service Parts | 12 |

Important Safety Instructions

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

SET UP YOUR FURNITURE PROPERLY

1. Ensure that all parts are assembled properly and fully tightened as per the instructions.
2. When placing in the desired location, ensure that all legs are resting on the same surface.

EXAMINE YOUR FURNITURE

Examine occasionally to ensure that there are no loose parts. If loose parts are found, they must be re-tightened fully before additional use.

OBSERVE WEIGHT LIMITS

The weight limits for the following products are listed below:

- | | |
|--|---|
| <input type="checkbox"/> Chair: 300 lbs | <input type="checkbox"/> Sofa: 700 lbs |
| <input type="checkbox"/> Swivel Chair: 300 lbs | <input type="checkbox"/> Rocking Chair: 300 lbs |
| <input type="checkbox"/> Loveseat: 500 lbs | <input type="checkbox"/> Chaise Lounge: 300 lbs |
| <input type="checkbox"/> Ottoman: 150 lbs | <input type="checkbox"/> Dining Table: 100 lbs |
| <input type="checkbox"/> Table: 50 lbs | <input type="checkbox"/> Dining Chair: 200 lbs |



CAUTION: If you overload your furniture, injuries can occur.

Warranty

THREE YEAR FRAME, WEAVE AND FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frame, weave and fabric to be free of manufacturing defects to the original purchaser for three years. For glass table top we warrant 30 days from the date of purchase.

WHAT IS NOT COVERED

This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty.

We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.


Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.Hamptonbay.com.

Pre-Assembly

PLANNING ASSEMBLY

To prevent damage, place all parts on a soft surface during assembly. Remove all protective caps before beginning assembly.

HARDWARE INCLUDED



AA



BB



CC



DD



EE



FF




GG



HH

| Part | Description | Quantity |
|------|-------------------------|----------|
| AA | Bolt (1/4 x 20 mm) | 21 |
| BB | Bolt (1/4 x 40 mm) | 18 |
| CC | Long Bolt (1/4 x 55 mm) | 2 |
| DD | Locking nut (6 mm) | 2 |
| EE | Washer (6 mm) | 43 |
| FF | Plastic washer (6mm) | 2 |
| GG | Hex wrench (4mm) | 1 |
| HH | Socket wrench | 1 |


PACKAGE CONTENTS (Chair)



| Part | Description | Quantity |
|------|--------------|----------|
| A | Seat | 1 |
| B | Back | 1 |
| C | Left Arm | 1 |
| D | Right Arm | 1 |
| E | Back Cushion | 1 |
| F | Seat Cushion | 1 |


1 Attaching the right arm

- Place the right arm (D) on a soft surface.
- Attach the seat (A) to the right arm (D) by aligning holes on the seat (A) with the holes on the right arm (D) and inserting bolts (BB) with washers (EE). Tighten half way using the Hex wrench (GG).




2 Attaching the back

- Put the back (B) metal side into the hole of arm(D).
- Attach right arm (D) to the back (B), fasten bolts (BB) and washer (EE). Tighten half way using the Hex wrench (GG).
- Insert two pins on the the seat (A) into the holes on back (B) fasten bolts (AA) and washer (EE). Tighten half way using the Hex wrench (GG).




3 Attaching the left arm

- Repeat step 1 and 2 to attach the left arm (C).




4 Completing the assembly

- Check and make adjustment as needed.
- Fully tighten all the bolts with the Hex wrench(GG).
- Place the seat cushion (F) and the back cushion (E) on the chair.
- This chair is now ready for your enjoyment.




PACKAGE CONTENTS (SOFA)



| Part | Description | Quantity |
|------|--------------|----------|
| C | Left Arm | 1 |
| D | Right Arm | 1 |
| E | Back Cushion | 3 |
| F | Seat Cushion | 3 |
| G | Seat | 1 |
| H | Back | 1 |


1 Attaching the right arm

- Place the right arm (D) on a soft surface.
- Attach the seat (G) to the right arm (D) by aligning holes on the seat (G) with the holes on the right arm (D) and inserting bolts (BB) with washers (EE). Tighten half way using the Hex wrench (GG).




2 Attaching the back

- Put the back (H) metal side into the hole of arm(D).
- Attach right arm (D) to the back (H), fasten bolts (BB) and washer (EE). Tighten half way using the Hex wrench (GG).
- Insert three pins on the seat (G) into the holes on back (H) fasten bolts (AA) and washer (EE). Tighten half way using the Hex wrench (GG).




3 Attaching the left arm

- Repeat step 1 and 2 to attach the left arm (C).




4 Completing the assembly

- Check and make adjustment as needed.
- Fully tighten all the bolts with the Hex wrench(GG) .
- Place the seat cushion (F) and the back cushion(E) on the sofa.
- This sofa is now ready for your enjoyment.



PACKAGE CONTENTS (STORAGE COFFEE TABLE)



| Part | Description | Quantity |
|------|-------------|----------|
| I | Table Top | 1 |
| J | Base | 1 |
| K | Side Skirts | 2 |
| L | Front Skirt | 1 |
| M | Back Skirt | 1 |


Assembly (65-516183-T)

1 Attaching to side skirts to the back skirt

- ☐ Place the back skirt (M) on a soft surface.
- ☐ Attach the right side skirt (K) to the back skirt (M), fasten with bolts (AA) and washer (EE). Tighten half way using the Hex wrench (GG).
- ☐ Repeat previous step for the other side skirt.


Fig1

Fig 2




2 Attaching the base

- ☐ Put the base (J) on side skirt (K) as shown, fasten with bolts (AA) with washers (EE). Tighten half way using the Hex wrench (GG) .




3 Attaching the front side

- ☐ Put the assembling table onto the front (L).
- ☐ Tighten with bolts (AA) with washers (EE). Do not fully tighten.




4 Fastening the bolts

- ☐ Turn the assembling storage box upward as shown.
- ☐ Check and make adjustment as needed. Fully tighten all the bolts (AA) with Hex wrench (GG).




5 Attaching the top

- Make the holes on (M) and top (I) in a line.
- Put long bolts(CC) going through the holes and tighten with locking nuts (DD) by using socket wrench (HH) and Hex wrench(GG), fully tighten.



6 Completing the assembly

- Attach side skirt (K) by aligning hole on the top (I) with the hole on the piston.
 - Insert a bolt (AA) with washer (EE) and (FF), fully tighten with Hex wrench (GG).
 - Repeat below step for the other side skirt (K).
- This table is now ready for your enjoyment.



Cleaning and Maintenance

- ❑ Before using, wipe with a clean, dry cloth. Do not use bleach or solvents. When not in use, store furniture in a cool, dry place.
- ❑ Do not use bleach or solvents on fabrics. When cleaning the table top make sure to use a soft, clean cloth that does not bleed color as well.
- ❑ Wash the frame with a mild solution of soap and water, rinse with clean water, and dry thoroughly.
- ❑ Cushions may also be cleaned by hand with a mild solution of soap and water. Rinse the cushion cover thoroughly and allow to drip dry. The back cushion and pillow should be spot cleaned with a soft cloth. Do not machine wash or tumble dry, as cushions may shrink. Do not use bleach or solvents on fabrics. Never use cleaners that contain acid or abrasive materials.
- ❑ Use and operation: To improve the lifespan of this furniture, cover when not in use and store in a dry place in the off season.

| Part | Description | Quantity |
|------|------------------|----------|
| A | Seat | 1 |
| B | Back | 1 |
| C | Left Arm | 3 |
| D | Right Arm | 3 |
| E | Back Cushion | 5 |
| F | Seat Cushion | 5 |
| G | The Seat of Sofa | 1 |
| H | The Back of Sofa | 1 |
| I | Table Top | 1 |
| J | Base | 1 |
| K | Side Skirts | 2 |
| L | Front Skirt | 1 |
| M | Back Skirt | 1 |

HAMPTON BAY®

Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Retain this manual for future use.