


USE AND CARE GUIDE

COLOR CHANGING SMART WALL LIGHT



Questions, problems, missing parts? Before returning to the store,
call Home Decorators Customer Service
8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-877-592-5233

[HOMEDEPOT.COM/HUBSPACE](https://www.homedepot.com/hubspace)

THANK YOU

We appreciate the trust and confidence you have placed in Home Decorators Collection through the purchase of this light fixture. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Decorators Collection!

Table of Contents

Safety Information	2	Tools Required (Not Included)	3
FCC Notice	2	Hardware Included	3
Warranty	2	Package Contents	4
Limited Warranty	2	Installation	5
Pre-Installation	3	Care and Cleaning	9
Planning Installation	3	Troubleshooting	9

Safety Information

Read and understand this entire manual before you attempt to assemble, install, or operate this product.



WARNING: Before starting the removal of an old fixture or the installation of this fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box.

Consult a qualified electrician if you have any electrical questions or need to replace the driver.

If you have any non-electrical questions about this fixture, please contact our Customer Service Team at 1-877-592-5233 or visit www.HOMEDEPOT.com/HUBSPACE.

Keep your receipt and these instructions for proof of purchase.

FCC NOTICE

NOTE: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference
(2) This device must accept any interference received, including interference that may cause undesired operation.



- ☐ Reorient or relocate the receiving antenna.
- ☐ Increase the separation between the device and the receiver.
- ☐ Connect the equipment to an outlet on a circuit different from that to which the receiver is located.
- ☐ Consult the dealer or an experienced radio/TV technician for help.

Warranty

LIMITED WARRANTY

The manufacturer warrants this lighting fixture to be free from defects in materials and workmanship for a period of five (5) years from date of purchase. This warranty applies only to the original consumer purchaser and only to products used in normal use and service. If this product is found to be defective, the manufacturer's only obligation, and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alterations, neglect or mishandling. This warranty shall not apply to any product that is found to have been improperly installed, setup, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, or faulty installation, or any other failure not relating to faulty material or workmanship. This warranty shall not apply to the finish on any portion of the product, such as surface and/or weathering, as this is considered normal wear and tear. The manufacturer does not warrant and specially disclaims any warranty, whether express or implied, of fitness for a particular purpose, other than the warranty contained herein. The manufacturer specifically disclaims any liability and shall not be liable for any consequential or incidental loss or damage, including but not limited to any labor or expense costs involved in the replacement or repair of said product.

Contact the Customer Service Team at 1-877-592-5233 or visit www.HOMEDEPOT.com.

Pre-Installation

PLANNING INSTALLATION

Before beginning installation, make sure all parts are included using the Hardware Included and Package Contents sections. If any part is missing or damaged, do not attempt to assemble, install, or operate the product.

To avoid damaging this product, place it on a soft, non-abrasive surface, such as carpet or cardboard.

TOOLS REQUIRED (NOT INCLUDED)



Phillips
screwdriver



Safety goggles



Wire stripper



Flat head
screwdriver



Ladder



Wire cutters




Electrical tape


HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.



AA




BB

Part	Description	Quantity
AA	Bracket mounting screw	2
BB	Wire nut	3

Pre-Installation (continued)

PACKAGE CONTENTS




Part	Description	Quantity
A	Mounting bracket	1
B	Light fixture	1
C	Lock nut	2
D	Ground screw	1
E	Light fixture mounting screw	2

Installation


1 Installing the mounting bracket

- Thread the fixture mounting screws (E) into the provided holes of the mounting bracket (A).
- Pull the supply wires out from the outlet box (1) and mount the mounting bracket (A) using the bracket mounting screws (AA).



2 Connecting the wires


- Connect the black supply wire to the black fixture wire using a wire nut (BB).
- Connect the white supply wire to the white fixture wire using a wire nut (BB).
- Connect the ground wire from the fixture to the ground wire from the outlet box to the ground screw (D) of the mounting bracket (A).
- Wrap all wire connections with electrical tape for more secure connections.
- Carefully tuck the wires and wire nuts (BB) into the outlet box.



NOTE: If you have electrical questions, consult your local electrical code for approved grounding methods.

3 Installing the fixture

- Place the fixture (B) onto the fixture mounting screws (E) and secure it into place by using the lock nuts (C).
- Turn the power on at the circuit breaker or fuse box.
- Turn the light switch on to activate the fixture.



Controlling the Light with Bluetooth® wireless technology and Wi-Fi® network

1 Download the Hubspace app


- Download the Hubspace app from the App Store or the Google Play Store to your mobile device.
- Turn on the Bluetooth® and Wi-Fi® functions of the smart device to ensure the Wi-Fi® signal at home is stable and reliable.
- Open the Hubspace app.



NOTICE: To register, enter your email address and a password. Or, login if you already have an account.



NOTICE: Bluetooth enabled smart devices typically have a range of approximately 33 ft. (10 m). Attempting to pair your smart device to the wall light beyond the intended range can result in inconsistent performance or failure to connect.



2 Select and pair the LED wall light



- In the Hubspace app screen, tap the plus sign “+” in the upper right corner.
- Scan your product's QR code or quick start guide. If the QR code cannot be scanned for some reason, you can enter the code manually. Tap Enter Code and follow the instructions.
- Name the LED wall light identified and assign it to a room, for example “Wall light.”
- Connect your device to power and follow the instructions on screen.



NOTICE FOR LIGHTING AND FAN PRODUCTS ONLY:


If you are unable to access the QR code for your light, you can put it into discovery mode with the following sequence:

- Switch the device off and on 5 times. The light will pulse to show that it can now be discovered.
- In the Hubspace app, tap the plus sign in the upper right corner and follow the instructions to discover devices. More than one device can be added at a time using this method.




3 Connecting to a Wi-Fi® network

- Click “ON” on the right side of the light named “Wall light” in the screen
- Click Setting symbol  in lower right corner after
- select an available Wi-Fi® signal from the drop-down list , and connect the light to the Wi-Fi® signal.



4 Controlling the LED wall light

- Controllable functions include: White Temperature, Recent colors, Presets, Name, the connected Wi-Fi, Room, Time Zone and more.



Controlling the Light with Bluetooth® wireless technology and Wi-Fi® network (continued)

5 Set up your voice assistant




- In the Hubspace app, tap the Hubspace button.
- Select the Integrations tab, choose your voice assistant and follow the instructions.

6 Remove the LED wall light

- Click the “Remove Device” in the “Setting” interface to remove the lamp.



NOTICE: If you would use the Hubspace app to rescan the wall light, it must be removed first.



Care and Cleaning



CAUTION: Before attempting to clean the fixture, disconnect the power to the fixture.

- Clean the fixture with a soft, dry cloth.
- Do not use cleaners with chemicals, solvents, or harsh abrasives.

Troubleshooting



WARNING: Before doing any work on the fixture, disconnect power to the light fixture.

Minor problems often can be fixed without the help of an electrician.

Problem	Possible Cause	Solution
The fixture will not light.		<input type="checkbox"/> Ensure the power supply is on.
	The circuit breaker is off.	<input type="checkbox"/> Ensure the circuit breaker is in the on position.
	There is a bad connection.	<input type="checkbox"/> Check to ensure proper wire connections are made. <input type="checkbox"/> Contact a qualified electrician.
	There is a defective switch.	<input type="checkbox"/> Contact a qualified electrician.
The fuse blows or the circuit breaker trips when the light is turned on.	The wires are crossed or the power wire is grounding out.	<input type="checkbox"/> Check the wire connections. <input type="checkbox"/> Contact a qualified electrician or call customer service 1-877-592-5233.
The light fixture flickers or makes a buzzing sound.	The dimmer circuit is not compatible with the product.	<input type="checkbox"/> Check the product page at HomeDepot.com for a list of compatible dimmers.
	The dimming circuit is set outside the dimming range of the product.	<input type="checkbox"/> Turn or slide the dimmer switch to adjust the light output until the flickering or buzzing stops.
The Bluetooth wall light will not pair with a smart device.	The Bluetooth feature is turned off on the smart device.	<input type="checkbox"/> Ensure the Bluetooth function is turned on within the device settings. A Bluetooth symbol should be visible somewhere on the device screen. <input type="checkbox"/> Charge up the device being paired with the wall light. Smart power management may have turned off the Bluetooth function when low on power.
	The smart device is out of range of the Bluetooth wall light.	<input type="checkbox"/> Be sure the wall light is within 33 ft. (10 m) of the smart device.
	The smart device is not discoverable.	<input type="checkbox"/> Turn on "Discoverable" mode on the device to allow the wall light and smart device to recognize each other.
	The smart device did not automatically connect to the Bluetooth wall light.	<input type="checkbox"/> Confirm the device's "Discoverable" mode is turned on to allow the wall light and smart device to recognize each other. <input type="checkbox"/> Go to the pairing list on the device and manually connect the device to the wall light.
	The wall light is not powered on.	<input type="checkbox"/> Make sure the wall light is properly connected and the power is turned on. <input type="checkbox"/> Ensure the circuit breaker is in the on position.
	Interference is causing confusion with the connection.	<input type="checkbox"/> Power both the device and the wall light off and back on. <input type="checkbox"/> Delete the wall light from the smart device and rediscover it. <input type="checkbox"/> Move away from Wi-Fi routers or computers that could be causing interference.
Hubspace device use question.	My Hubspace device is not connecting to Wi-Fi.	<input type="checkbox"/> Make sure your device is connected to a power source. <input type="checkbox"/> Your Internet connection or Wi-Fi network may be down.
	My device cannot find any Wi-Fi networks.	<input type="checkbox"/> Make sure you have a 2.4GHz capable Wi-Fi network within range of the device you are trying to add.
	My device is in a location that does not have Wi-Fi. Can I still use it with the Hubspace app?	<input type="checkbox"/> Yes. <input type="checkbox"/> Use the app on a phone with an Internet connection like LTE. <input type="checkbox"/> The phone must be within Bluetooth range of your Hubspace device.
	I cannot find the QR code.	<input type="checkbox"/> Look for it where other stickers are on the product. A copy of the QR code is also included in your device's documentation.
	The QR code has become damaged. How do I add the device?	<input type="checkbox"/> Under the QR code are numbers. You can enter those in manually instead of scanning the code.
	How do I reset the device?	<input type="checkbox"/> Remove the device from your account, then add it back. <input type="checkbox"/> Devices also reset when they transfer to a new account.
Hubspace device use question.	A device is on another account. How do I transfer it?	<input type="checkbox"/> Scan the QR code and it will transfer to your account.
	My device is offline for long periods of time.	<input type="checkbox"/> Make sure your Wi-Fi signal strength is sufficient. You may need to move your router, use mesh Wi-Fi, or Wi-Fi extenders.
	The device is on and I scanned the QR code, but the app cannot connect to it.	<input type="checkbox"/> Turn off Bluetooth on your phone and turn it back on. Then, scan the QR code.
	Can I scan the same QR code to add multiple products?	<input type="checkbox"/> No. Each product has a unique QR code.

HOME DECORATORS COLLECTION®

Questions, problems, missing parts? Before returning to the store,
call Home Decorators Customer Service
8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-877-592-5233

HOMEDEPOT.COM/HUBSPACE

Retain this manual for future use.