

Installation & Safety Guide

Before You Begin:

Inspect All Parts: Unpack and lay out all components (swing chair, ropes, carabiners, suspension kit) on a clean surface. Ensure no damage from shipping.

Choose Location & Support: This is the most critical step. You **MUST** attach the swing to a structure that is structurally sound and can safely support dynamic weight (minimum 300 lbs). Examples include a sturdy tree branch (min. 8" diameter), a solid ceiling joist in a basement or covered patio, or a heavy-duty outdoor beam. **Do not** attach to gutter pipes, decorative fixtures, or unverified structures.

Gather Tools: You will likely need a sturdy ladder, a tape measure, a drill with appropriate bits (for pilot holes if mounting to wood), and the provided wrench or hex key (if included in your kit).

Assembly & Hanging Steps:

Step 1: Prepare the Swing Seat

If your swing chair arrives with ropes gathered, gently extend the ropes and ensure the seat is untwisted. Verify that all knots on the seat itself are tight and secure.

Step 2: Install the Suspension Point

Using your chosen support structure, install the provided eye bolts or hooks. They must be screwed or bolted directly into the center of a solid wood beam or joist. Use the included locking nuts or washers. For trees, use a tree strap designed to protect the bark; never wrap rope directly around a thin branch. The hanging point should be at a height that allows the seated child's feet to be comfortably off the ground when the swing is at rest.

Step 3: Attach the Swing

Connect the carabiners or heavy-duty hooks from the swing's top ropes to the installed suspension points. Ensure all connections are **fully closed and locked**. Double-check that the swing is level.

Step 4: Final Safety Check

Before allowing a child to use the swing, perform this test: Apply gradual, firm adult weight (up to the rated capacity) to the center of the seat, checking for any unusual sounds, shifting, or strain on the support point. Ensure the swing has ample clearance (at least 6 feet in front and behind) from walls, furniture, or other obstacles.

Important Safety Warnings:

Supervision Required: Always supervise children using the swing.

Weight & Age Limit: Adhere strictly to the maximum weight capacity (230 lbs). The product is designed for young children.

Regular Inspection: Before each use, inspect ropes, carabiners, knots, and the support point for wear, fraying, or damage. Do not use if any part appears compromised.

Proper Use: Instruct children to sit in the center of the swing and hold the ropes. Do not stand, kneel, or use it recklessly.

Environmental Caution: For prolonged outdoor use, consider taking the swing indoors during severe weather to prolong its life.