LA CROSSE TECHNOLOGY



SOLUINA LIGHT ALARM CLOCK

SET UP GUIDE

MODEL NUMBER C79141

Table of Contents

Initial Setup
Buttons & Ports
LCD Display
LCD Display Brightness
Auto-Dim Settings
USB Charging Port
Temperature & Humidity

ALARMS

02	Natural Light Alarm	07
03	Setting the Light Alarm	08
04	Setting the Sound Alarm	09
05	Snoozing the Sound Alarm	10
05		
06		
06		

LIGHT MODES

Selecting Your Light Mode	11
Color Cycle Mode	12
Evening Mode	13
Guided Breathing Mode	14
Comfort Meter Mode	15
Color Select Mode	16
Glow Color Options	16

APPENDIX

BASICS

Specifications	
Warranty	
Cautions/Statements	18
Recycling & Disposal	

SUPPORT

17	Support Information	21
18	Factory Reset	21
-20	Stay in Touch	21



Initial Setup

Power Up

Insert the 5V Power Adapter into an outlet, and then plug it into the AC Jack on the bottom of the alarm clock. Next, remove the Insulation Tab from the Battery Compartment.

A greeting will appear on the LCD display and then your clock will move into the Settings Menu. The Color Cycle Light Mode will also begin.

Settings Menu Order

Language • Hour • Minutes • Year • Month • Date • Fahrenheit/Celsius Note: Weekday will set automatically after year, month, & date settings are adjusted.



Use the +/- buttons on the front of the clock to adjust the values.




Press the 2 button on the back of the clock to confirm selection and move to next step.




You may exit the Settings Menu at any time by tapping the Z^z button.



Buttons & Ports





1. DISPLAY ())

Tap to adjust backlight intensity or hold to enter Auto-Dim settings

2. PLUS/MINUS (+/-)

Tap to control glow light intensity or hold to adjust quickly

3. SNOOZE (z^z)

Tap to snooze the sound alarm, exit menus, or to turn the light off

4. LIGHT (*)

Tap to toggle through light modes. Tap \mathbf{Z}^{z} to confirm light mode selection

5. USB CHARGING PORT

Connect USB charging cable (not included)

6. SOUND ALARM (2)

Press to activate or hold to enter alarm settings

7. SET (🏠)

Hold to enter Settings Menu 8. LIGHT ALARM (漆) Press to activate or hold to enter alarm settings

9. FACTORY RESET

Press to restore factory settings

10. AC JACK


Connect AC adapter

11. BACKUP BATTERY

Saves settings and alarm function during power outages



LCD Display



Notes: Only one light and one sound alarm can be programmed. These can be set to go off together or at separate times.



LCD Display Brightness



Adjusting the LCD Display Brightness

Tap the 🔅 button to adjust the backlight intensity. There are 4 brightness levels, plus an off option.

Auto-Dim Settings

Program your LCD display to automatically dim during preselected times.

- Hold the button to enter the Auto-Dim Settings Menu.
- Tap the +/- buttons to turn the Auto-Dim feature on or off. Tap : to confirm.
- Tap the +/- buttons to adjust the start time. Tap to confirm.
- Tap the +/- buttons to adjust the stop time. Tap to confirm and exit.




BASICS

USB Charging Port

There is a 1 Amp USB Charging Port located on the right side of your alarm clock.

- Connect your external device's USB charging cable (not included) into the USB Charging Port.
- Charging times will vary.
- USB Power Output: 1 Amp Maximum Current

Temperature & Humidity



View real-time indoor temperature & humidity data on your alarm clock.



Fahrenheit



Celsius

You can select Fahrenheit or Celsius in the main Settings Menu.

ALARMS

Natural Light Alarm


The Soluna Light Alarm Clock is equipped with a glowing Light Alarm that simulates the sunrise. Use the Light Alarm to wake up peacefully and help reset your circadian rhythm.



Gradual Wake Up

The Light Alarm will begin 30 minutes before your set alarm time. The light will gradually increase in intensity until reaching full brightness at your set alarm time. The light will remain on and at full power until a button is pressed.

Example:



Based on 7:00am alarm time

Note: If you set an alarm for less than 30 minutes from the current time, the Light Alarm will accelerate the brightness accordingly.

Setting the Light Alarm

Setting the Light Alarm

- Hold the ☆ button on the back of the clock to enter the Light Alarm Settings Menu.
 DAILY ALARM will appear on the LCD.
- Use the +/- buttons to select your alarm frequency. Choose from Daily (1-7), Weekday (1-5), or Weekend (6-7) options. Press 🔅 to confirm.
- Next, Use the +/- buttons to set your desired time. Press 🔅 to confirm.
- Your Light Alarm is now activated, indicated by ^(*)/_(*) icon and alarm frequency (1-5, 1-7, or 6-7) on the LCD.

Activating & Deactivating the Light Alarm


- Press the 🔅 button on the back of the clock to view your Light Alarm time and activate/deactivate the alarm.
- The ⁽¹⁾/₍₂₎ icon and alarm frequency will appear on the LCD when the alarm is active.

Notes: The 1-7 Daily Alarm is the default alarm frequency. There is no sound with the Light Alarm. If a sound alarm is wanted, you will need to activate the Melody Sound Alarm.

ALARM FREQUENCIES

]AILY ALARM ™ &

> **1-7 Daily Alarm** (Monday–Sunday)



1-5 Weekday Alarm (Monday–Friday)



6-7 Weekend Alarm (Saturday–Sunday)

Only one light and one sound alarm can be programmed. These can be set to go off together or at separate times.

Setting the Sound Alarm

Setting the Melody Sound Alarm

- Use the +/- buttons to select your alarm frequency. Choose from Daily (1-7), Weekday (1-5), or Weekend (6-7) options. Press ∑ to confirm.
- Next, use the +/- buttons to set your desired snooze duration (5 to 120 minutes).
 Press ∑ to confirm and to exit the Sound Alarm Settings Menu.

Activating & Deactivating the Sound Alarm

- Press the 2 button on the back of the clock to view your Sound Alarm time and activate/ deactivate the alarm.
- 2. The ☆ icon and alarm frequency will appear on the LCD when the alarm is active.



Note: The 1-7 Daily Alarm is the default alarm frequency.




Melody Sound Alarm

Gradual Wake Up

The gentle Melody Sound Alarm will increase in volume over a 5-minute period. After the 5-minute time frame, the alarm will stop if not snoozed or turned off. To turn off a sounding alarm, press any button besides the snooze button (\mathbf{z}^z) .





Based on 7:15am alarm time



Snooze Duration Countdown

After the snooze button is pressed, the snooze duration countdown will appear on the LCD.



WHAT'S YOUR GLOW?

The Soluna Light Alarm Clock features 5 light modes with 20 unique color options, ensuring there's a glow for every day and mood.

Selecting Your Light Mode



- 1. Tap the 👎 button to toggle through the different light modes.
- Use the +/- buttons to adjust any additional glow color options within the Guided Breathing and Color Select modes.
- There are 2 ways to confirm your selection and start the light mode. Either tap the Z^z button or simply wait 5 seconds. The selected light mode will then begin.



Use the +/- buttons to adjust the light's brightness level.



To shut off the current light mode, tap the Z^z button.

Light Mode Options:

- Color Cycle
- Evening
- Guided Breathing
- Comfort Meter
- Color Select

LIGHT MODES

Color Cycle Mode

When using the Color Cycle Mode, the light will gradually shift through all of the glow color options.

How to Activate Color Cycle Mode

- Tap the the button to toggle through the light modes. CYCLE will appear on the LCD.
- There are 2 ways to confirm your selection and start the light mode. Either tap the Z² button or simply wait 5 seconds. The Color Cycle Mode will now begin.



Color Cycle Examples







Use the +/- buttons to adjust the light's brightness level. To shut off the light mode, tap the Z^{z} button.

Evening Mode

The Evening Mode is a 30-minute cycle designed to simulate the setting of the sun. Simply start the mode before bed and the light will gradually dim and shift in color while you fall asleep.



How to Activate Evening Mode

- Tap the toto to toggle through the light modes. EVENING will appear on the LCD.
- There are 2 ways to confirm your selection and start the light mode. Either tap the Z^z button or simply wait 5 seconds. The Evening Mode will now begin.



9:40PM

9:50PM

10:00PM

The Evening Mode will last a total of 30 minutes. Press the Z^z button at any time to end the light mode.

Guided Breathing Mode

The Guided Breathing Mode will walk you through a 10-minute deep breathing exercise. Simply inhale and exhale as the colors change. To further assist you, the LCD will also display your inhale and exhale times.

How to Activate Guided Breathing Mode

- 1. Tap the [♥] button to toggle through the light modes. BREATHING will appear on the LCD.
- Use the +/- buttons to choose the glow color. Select from three options: Energy, Warmth, or Calm.
- There are 2 ways to confirm your selection and start the light mode. Either tap the Z² button or simply wait 5 seconds. The Guided Breathing Mode will now begin.



Energy

Warmth

Calm

Use the +/- buttons to adjust the light's brightness level.

The breathing exercise will last a total of 10 minutes. Press the Z^{z} button at any time to end the exercise.

LIGHT MODES

Comfort Meter Mode

In the Comfort Meter Mode, the color changes according to the current indoor humidity level, so you can monitor the comfort of your home at a quick glance.

How to Activate Comfort Meter Mode

- 1. Tap the 💗 button to toggle through the light modes. COMFORT will appear on the LCD.
- There are 2 ways to confirm your selection and start the light mode. Either tap the Z^z button or simply wait 5 seconds. The Comfort Meter Mode will now begin.



1% to 25% RH



76% to 83% RH



26% to 39% RH



84% to 99% RH



40% to 75% RH

Use the +/- buttons to adjust the light's brightness level.

To shut off the light mode, tap the Z^z button.

LIGHT MODES

Color Select Mode

Use the Color Select Mode to choose your favorite glow color.



Glow Color Options


How to Activate the Color Select Mode

- Tap the * button to toggle through the light modes. PICK COLOR will appear on the LCD.
- 2. Use the +/- buttons to choose your glow color.
- There are 2 ways to confirm your selection and start the light mode. Either tap the Z^z button or simply wait 5 seconds. The Color Select Mode will now begin.




Use the +/- buttons to adjust the light's brightness level. To shut off the light mode, tap the Z^z button.

Specifications







6.81-in. (17.30 cm)

2.69-in. (6.84 cm)

Power Requirements:

Primary Power: 5.0V Power Adapter (Included) AC6: HX12H-0501500-AU-001

The plug on the power adapter is intended to serve as the disconnect device, the socket-outlet shall be installed near the equipment and shall be easily accessible.

Battery Backup: 1 "CR2032" Coin Cell Battery (Included)

In the event of a power outage, the Battery Backup will keep time. If any alarm was set, the alarm will beep at the set time.

LCD Brightness: 4 Intensity Levels + OFF

(Programmable Auto-Dim Backlight Option)

Glow Light Brightness: 5 Intensity Levels + OFF

The Evening Mode is preprogrammed and the brightness is not adjustable.

USB Charging Port: 1 Amp Maximum Current (Charging Cord Not Included)

Programmable Snooze Duration: 5 to 120 Minutes

Indoor Temperature Range: 32°F to 99°F (0°C to 37°C)

Indoor Humidity Range: 10% to 99% RH

Language Options: English, Spanish, French, and German (Translation Available for Menus & Calendar)

Warranty

La Crosse Technology, Ltd. provides a 1-year limited time warranty (from date of purchase) on this product, relating to manufacturing defects in materials and workmanship.

For full warranty details, you can visit: www.lacrossetechnology.com/support

La Crosse Technology, Ltd • 2830 S. 26th Street • La Crosse, WI 54601

Battery Warning



WARNING

- 1. This product contains a button battery.
- If swallowed, it could cause severe injury or death in just 2 hours.
- 3. Seek medical attention immediately.

WARNING: KEEP BATTERIES OUT OF REACH OF CHILDREN

- Swallowing may lead to serious injury in as little as 2 hours or death, due to chemical burns and potential perforation of the esophagus.
- If you suspect your child has swallowed or inserted a button battery, immediately seek urgent medical assistance.
- Examine devices and make sure the battery compartment is correctly secured, e.g. that the screw or other mechanical fastener is tightened.
- 4. Do not use if compartment is not secure.
- Dispose of used button batteries immediately and safely. Flat batteries can still be dangerous.
- Tell others about the risk associated with button batteries and how to keep their children safe.

Care & Maintenance

- Do not mix old and new batteries.
- Do not mix Alkaline, Lithium, standard, or rechargeable batteries.
- Always purchase the correct size and grade of battery most suitable for intended use.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries have with correct polarity (+ / -).
- Remove batteries from equipment that will not to be used for an extended period.
- · Promptly remove expired batteries.

Caution!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized changes or modifications to this equipment. Such changes or modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher.

This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.

Canada Statement

This Class B digital apparatus complies with Canadian ICES-003. Operation is subject to the following two conditions:

 This device may not cause interference.
This device must accept any interference, including interference that may cause undesired operation of the device.

California Residents

🔨 WARNING:

This product can expose you to chemicals including styrene, which is known in the State of California to cause cancer.

For more information, go to: www.P65Warnings.ca.gov

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Recycling & Disposal

Please consider the environment when deciding to dispose of this product. Although household electronics are generally safe to use on a daily basis, incorrect disposal can cause negative and potentially irreversible impacts on our environment.

Check with local donation centers to see if your product can be donated for future use. If disposal is the only option, federal agencies, local governments, and certified retailers may have electronic recycling programs in place. Programs may vary based on location.

SUPPORT

Having Trouble? We're here to help.

For detailed product videos, manuals, and more, visit our support website: www.lacrossetechnology.com/support

Make sure you have your product's model number handy (C79141)

Need Additional Support? Call our Friendly Customer Support Representatives

Phone Number: 1.877.408.2678

Representatives are available Monday-Friday, 8:00am to 6:00pm CST

Factory Reset



,

Stay in Touch

Ask questions, watch set up videos, and provide feedback on our social media outlets.



Follow La Crosse Technology on Youtube, Facebook, Twitter, and Instagram.

If you're still experiencing issues, use a pen or paper clip to press the factory **RESET** button on the back of the clock.



LA CROSSE® TECHNOLOGY

MORNING CACHE AND CONFORT AND RANK AND RANK AND RANK AND REVERS AND REVEAL AN