

Adjustable Step Stool

1. Safety Guidelines

- Always supervise children during use.
- Do not exceed the maximum weight limit of 200 lbs (90.7 kg).
- Ensure anti-slip rubber pads are securely attached before each use.
- Place the stool on a flat, stable surface. Avoid uneven or slippery floors.
- Keep away from open flames, heaters, or hazardous edges.

2. Assembly Instructions

Tools Included: Screws, hex key (if applicable).

Steps:

1. Lay out all parts and check for completeness.
2. Attach the side armrests to the base frame using provided screws.
3. Slide the adjustable platform onto the frame rails at the desired height (2 height settings).
4. Secure the platform by tightening screws with the hex key.
5. Attach rubber pads to the base legs.

3. Adjusting the Height

1. **For Younger Children (18 months–3 years):** Set the platform to the lower position.
2. **For Older Children (3–5 years):** Raise the platform to the higher position.
3. Always ensure screws are tightened securely after adjustment.

4. Using the Stool

- **Bathroom:** Helps toddlers reach sinks or step into tubs safely.
- **Kitchen:** Enables children to assist with washing hands or light tasks.
- **Bedroom:** Acts as a step for climbing onto beds safely.
- **General Use:** Always hold side handles for stability while climbing.

5. Cleaning & Maintenance

1. Wipe surfaces with a soft cloth dampened with mild soap and water.
2. Avoid abrasive cleaners or chemicals to preserve the finish.
3. Dry thoroughly after use in damp areas.
4. Regularly check screws and rubber pads for wear or looseness.

6. Important Notes

- Do not allow children to jump, stand on edges, or misuse the stool.
- Store in a dry area to prolong material durability.
- Replace worn or damaged parts immediately.

7. Specifications

- **Material:** Eco-friendly, moisture-resistant wood.
- **Dimensions:** Two-step design with adjustable platform (approx. 12"–16" height).
- **Weight Capacity:** 200 lbs (90.7 kg).