

Maintenance

1. Always protect furniture with outdoor covers — you never know when a summer storm can hit! It's best to make sure the furniture is as dry as possible before putting covers on or storing long term , so residual moisture doesn't mildew. We suggest putting covers on whenever you go out of town and during the off-season, too.
2. Store cushions separately — preferably indoors — where they can stay dry. Be sure to remove cushions while cleaning your wicker.
3. Use a soft bristle brush to keep dust and dirt off your wicker furniture.
4. Clean the product with a damp cloth.
5. Don't power wash your wicker furniture — like abrasive cleaners, they can wear finishes and coloring down.
6. Check all components and bolts to be secured regularly.
7. Please note: the weight limit of swing chair is 510 lbs max.