


Item # 1000 000 000

Model: A211043601

HAMPTON BAY®

USE AND CARE GUIDE

WINDSOR SWIVEL DINING CHAIR-BARE



Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. - 7 p.m., EST, Monday-Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this Chair. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

Table of Contents	2	Pre-Assembly	4
Important Safety Instructions	2	Planning assembly	4
Warranty	2	Hardware Included	4
What is Covered	2	Package Contents	5
What is Not Covered	2	Assembly	6
		Care and Cleaning	8

Important Safety Instructions

SAVE THESE INSTRUCTIONS READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

1. Close supervision is necessary when this furnishing is used by, or near children, or disabled persons.
2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
3. Some parts may contain sharp edges. Wear protective gloves.
4. Please count the parts before assembly.
5. Set up your furniture properly. Ensure that all parts are assembled properly and fully tightened as per instructions. When placing in the desired location, ensure that all legs are resting on the same surface. You may adjust the leg levelers as required to ensure that the item stands in a level position.

6. Examine occasionally to ensure that there are no loose parts. If loose parts are found, they must be re-tightened fully before additional use.



DANGER: Keep children and parts away from the assembly area.



WARNING: To avoid destroying the finish, please handle the surface by using a soft cloth instead of your bare hands. Due to the nature of iron, surface oxidation (rusting) will occur once these protective coatings are scratched. We recommend immediate touch-up with rust inhibiting paint (not included).



CAUTION: Do NOT over tighten any of the bolts or nuts.

Warranty

2 YEAR WARRANTY

WHAT IS COVERED

This limited warranty is extended to the original purchaser and applies to defects in materials and workmanship of your item provided the item is maintained with care and used only for personal, residential purposes. The item is warranted to be free from defects in material or workmanship for a period of 2 years.

WHAT IS NOT COVERED

We do not reimburse for transportation of delivery costs, or compensate the individual or any outside party for assembling or disassembling the product.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit HAMPTONBAY.COM.

Production Number: 2020xxxxxxx

Pre-Assembly


PLANNING ASSEMBLY

Before beginning assembly of this product, make sure all parts are present. Compare parts with the Hardware Included and Package Contents lists. If any part is missing or damaged, do not attempt to assemble the product. Contact customer service for replacement parts.

HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.




Part	Part Number	Description	Quantity
AA	H010030035	Bolt M6*40	10
BB	H010030044	Bolt M8*45	4
CC	H050020011	Spring washer M6	10
DD	H050010023	Flat washer M6	10
EE	H050020016	Spring washer M8	4
FF	H050010017	Flat washer M8	4
GG	R990020516	Nut M8	4
HH	H090030002	Wrench M6	1
II	H090030005	Wrench M8	2
JJ	P000500937	Big washer	4

Pre-Assembly


PACKAGE CONTENTS




A



B1




B2



C




D




E



F



G



H

Part	Part Number	Description	Quantity
A	P001500068	Back	1
B1	P001400251	Armrest (Left)	1
B2	P001400252	Armrest (Right)	1
C	P001600202	Seat	1
D	P000501273	T-Shape Support	1
E	P005400437	Base	1
F	P001800130	Cushion	1
G	P001700107	Back cushion	1
H		Foot pad	8


Assembly

1 Attaching the Back and Armrests

- Insert the bolt of the back (A) to the mounting holes of left and right armrest (B1/B2) and secure using bolt (AA), spring washer (CC) and flat washer (DD) with the wrench (HH), do not tighten at this step.



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.




2 Attaching the Seat

- Connect the seat (C) to the back (A) and left and right armrest (B1/B2) using bolt (AA), spring washer (CC) and flat washer (DD) with the wrench (HH), do not tighten at this step.



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.




3 Attaching the T-Shape Support

Connect the T-shape support (D) to seat (C) using bolt (BB), spring washer (EE) and flat washer (FF) with wrench (HH). Tighten all the bolts at this step.



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.




4 Attaching the Base

- Insert the T-shape support (D) to the base (E).



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.




Assembly

5 Placing the Cushions

- Place the cushion (F) and back cushion (G) on the chair and assembly is complete.



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.



Care and Cleaning

- Before using, clean the sectional completely with a soft dry towel.
- Do not use harsh abrasives or cleaners.
- When not in use, store in a cool, dry area.

HAMPTON BAY®

Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. - 7 p.m., EST, Monday-Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Retain this manual for future use.
