
Item # 1004 415 335/1004 250 146/1004 250 142 Model: A201001500/A211004200/A211004201

HAMPTON BAY

USE AND CARE GUIDE

WINDSOR SOFA



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday-Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

Table of Contents

Table of Contents	2
Important Safety Instructions	
Warranty	
What is Covered	
What is Not Covered	2

Pre-Assembly	3
Planning assembly	
Hardware Included	3
Package Contents	3
Assembly	4
Care and Cleaning	6

Important Safety Instructions

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- Some parts may contain sharp edges. Wear protective gloves.
- 2. Please count the parts before assembly.
- 3. Set up your furniture properly. Ensure that all parts are assembled properly and fully tightened as per instructions. When placing in the desired location, ensure that all legs are resting on the same surface. You may adjust the leg levelers as required to ensure that the item stands in a level position.
- 4. Examine occasionally to ensure that there are no loose parts. If loose parts are found, they must be re-tightened fully before additional use.



DANGER: Keep children and parts away from the assembly area.



WARNING: To avoid destroying the finish, please handle the surface by using a soft cloth instead of your bare hands. Due to the nature of iron, surface oxidation (rusting) will occur once these protective coatings are scratched. We recommend immediate touch-up with rust inhibiting paint (not included).



CAUTION: Do NOT over tighten any of the bolts or nuts.

Warranty

2 YEAR WARRANTY

WHAT IS COVERED

This limited warranty is extended to the original purchaser and applies to defects in materials and workmanship of your item provided the item is maintained with care and used only for personal, residential purposes. The item is warranted to be free from defects in material or workmanship for a period of 2 years.

WHAT IS NOT COVERED

We do not reimburse for transportation of delivery costs, or compensate the individual or any outside party for assembling or disassembling the product.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit HAMPTONBAY.COM.

Production Number: 20201870

Pre-Assembly

PLANNING ASSEMBLY


Before beginning assembly of this product, make sure all parts are present. Compare parts with the Hardware Included and Package Contents lists. If any part is missing or damaged, do not attempt to assemble the product. Contact customer service for replacement parts.

HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.












EE

Part	Description	Quantity		
AA	Bolt M6*40	12		
BB	Bolt M6*15	4		
CC	Spring washer M6	16		
DD	Flat washer M6	16		
EE	Wrench M6	1		

PACKAGE CONTENTS



Part	Description	Quantity		
A1	Handrail (Right)	1		
A2	Handrail (Left)	1		
В	Back	1		
С	Seat	1		
D	Cushion	3		
Е	Back cushion	3		
F	Leg	2		


Assembly

1 Attaching the Back and Seat

☐ Connect the Back (B) with Seat (C) using Bolt (AA), spring washer (CC) and washer (DD). Use wrench (EE) to loosely tighten the bolts.




NOTE: Do not fully tighten the bolts.




2 Attaching the Handrails(Left)

- ☐ Insert the hole on the Handrail (A2) on the bolt on the side of Back (B). Move the Handrail (A2) back and forwards and adjust the angle if you find difficult to insert the hole.
- Swivel forward the Handrail (A2) to be level with the Seat (C).



3 Attaching the Handrails(Left)

- ☐ Align the back (B) with the mounting holes in the Handrail (A2), connect them using Bolts (AA), spring washer (CC) and washer (DD). Use wrench (EE) to loosely tighten the bolts.
- Connect the Seat (C) with the Handrail (A2) using bolts (AA), spring washer (CC) and washer (DD). Use wrench (EE) to loosely tighten the bolts.




4 Attaching the Handrails (Right)

- ☐ Insert the hole on the Handrail (A1) on the bolt on the side of Back (B). Move the Handrail (A1) back and forwards and adjust the angle if you find difficult to insert the hole.
- Swivel forward the Handrail (A1) to be level with the Seat (C).



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.




HAMPTONBAY.COM.
Please contact 1-855-HD-HAMPTON for further assistance.

Assembly

5 Attaching the Handrails (Right)

- □ Align the back (B) with the mounting holes in the Handrail (A2), connect them using Bolts (AA), spring washer (CC) and washer (DD). Use wrench (EE) to loosely tighten the bolts.
- ☐ Connect the Seat (C) with the Handrail (A2) using bolts (AA), spring washer (CC) and washer (DD).




6 Attaching the Legs

□ Attach the Legs (F) to the Seat (C) using Bolts (BB), Spring washers (CC) and Flat washers (DD). Fully tighten the all bolts. Wrench (EE) is used in this step.



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.




Placing the Cushions

Place the Cushions (D) and Back cushions (E) on the Seat (C).



NOTE: To avoid destroying the finish, do not put the parts on the ground directly.



Care and Cleaning

Before	using,	clean the	Sofa com	pletely	with a	soft dr	y towel.

- Do not use harsh abrasives or cleaners.
- ☐ When not in use, store in a cool, dry area.

HAMPTON BAY

Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday-Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Retain this manual for future use.