

19.75"




Model No. 23LE31092  
SKU No. 1009537506

ASSEMBLY INSTRUCTIONS

(We recommend wearing proper clothing in order to prevent scratches that may occur during the assembly process.)  
Carefully unpack the contents from the tree's carton (Fig 1).  
Your tree will include the following components:

- A folding metal tree stand with (1) eyebolt.
- Plug with controller Button (Fig 7); which is pre-attached to your tree (Fig 5).
- (3) tree sections - labeled "A", "B" and "C", as shown in Fig 5.



ASSEMBLY OF THE TREE STAND

1. Remove the tree stand from the plastic bag, loosen the eye bolt and open the tree stand to form an "X".
2. Align the hole for the insertion of the eyebolt.
3. Insert the eyebolt and begin threading in a clockwise direction for a couple of rotations only, leaving enough room for the tree's pole from section "A" to be inserted into the assembled stand (Fig 2).
4. Place the tree stand in its desired location; as once the tree is fully assembled, it may become too difficult to move and relocate.



ASSEMBLY OF THE TREE

1. Locate the bottom section of the tree which is identified by a label on the outer branches marked "A" (Fig 5).
2. Remove the protective plastic cap from the end of the pole, (that is pinched to a point), and place that end into the tree stand. Be sure that the pointed end of the pole extends to the bottom of the stand.
3. Now tighten the eyebolt on the tree stand; being careful not to over-tighten (Fig 3).



4. Untie and remove the fabric strapping bounding the branches upright (Fig 6). **Caution:** Do not cut.
5. Gently guide the branches downward into place.
6. Beneath the canopy of section "A", contains cord and plug (Fig 8). Remove the twist-tie binding the cord together and insert the plug into a working electrical outlet. Section "A" will now be lit.



**LED23**

**POWER POLE TECHNOLOGY**  
**NOTE:** Your tree has been designed with Power Pole technology; allowing for each of the tree's remaining sections to light up automatically, upon a firm insertion of each lettered section (Fig 5).

7. Locate the next section of the tree which is identified by a label on the outer branches marked "B" (Fig 5).
8. Remove the protective plastic cap from the end of the pole on section "B"; insert that end onto the top of the pole of section "A" (Fig 4).



9. Once section "B" is fully inserted downward into section "A"; both section "A" and section "B" will now be lit.
10. Again, untie and remove the fabric strapping bounding the branches upright (Fig 6). **Caution:** Do not cut.
11. Gently guide the branches of section "B" downward into place.
12. Locate the top section of the tree which is identified by a label on the outer branches marked "C" (Fig 5).
13. Insert the top section "C" onto the top of section "B" (Fig 5).
14. Once section "C" is fully inserted downward into section "B"; your entire tree will now be lit.
15. Gently guide the branches of section "C" downward into place. Assembly is now completed. Proceed to spread & fluff the branch tips, to further enhance the tree's appearance, if needed.



MANUAL OPERATION:  
1. THE PLUG'S CONTROL BUTTON

1. The below pre-set color & function listing is available without attaching to the "HUBSPACE" account by use of the tree's plug control button (Fig 7).
  2. This button allows for "On" & "Off" manual operation of the tree's lighting system. (The green light, on the control button, indicates that the tree is in the "On" position).
  3. Pressing & holding the button for 2-3 seconds will place the tree's lighting system in the "Off" position. (The control button will remain dark, when in the "Off" position).
- NOTE:** When in the "On" position, continued/short pressing & releasing of the tree's control button will allow for the user to manually cycle through 30 of the tree's available 43 pre-set colors & "themed" function combinations.

- |                          |                              |
|--------------------------|------------------------------|
| 1. Steady - Warm White.  | 16. "Cinco de Mayo".         |
| 2. "Christmas".          | 17. "July 4 <sup>th</sup> ". |
| 3. "Hanukkah".           | 18. "Firework".              |
| 4. "Mistletoe".          | 19. "Halloween".             |
| 5. "Tinsel".             | 20. "Halloween 2".           |
| 6. "Santa's Party".      | 21. "Rainbow".               |
| 7. "North Pole".         | 22. "Double Rainbow".        |
| 8. "Rainbow Rudolf".     | 23. "Rainbow Road".          |
| 9. "Snowflake".          | 24. "Prism".                 |
| 10. "Snowfall".          | 25. "Under the Sea".         |
| 11. "White Star".        | 26. "Effervescent".          |
| 12. "Penguin Disco".     | 27. "Red Shift".             |
| 13. "Valentine's Day".   | 28. "Vote of Confidence".    |
| 14. "St. Patrick's Day". | 29. "Ping".                  |
| 15. "Easter Eggs".       | 30. "Monday".                |



2. CONNECTING TO THE HUBSPACE APP

1. Ensure that the tree's lighting is in the "On" position.
  2. Scan the QR code, located directly on the tree's control plug (Fig 8).
  3. On the App's main screen, tap the "+" button in the upper right corner. Once the next screen appears, select "Add Device".
  4. Follow the instructions within the App.
- NOTE:** An additional QR code is provided within the tree's instruction packet - affixed onto the "HUBSPACE Quick Start Guide". Follow these easy setup instructions.
- NOTE:** "HUBSPACE" needs a connection before you can utilize the product. Go to your phone's "Settings" and turn on the "Bluetooth".
- HUBSPACE only shows Wi-Fi networks that your device can use.
  - If you do not use your Wi-Fi network name when your attempt to connect your device, please check your router settings.

3. FEATURES OF THE HUBSPACE APP

1. The HUBSPACE APP will enable you to:
  - Change the color, brightness, and other settings of each individual bulb on the string light set to an RGB or white color.
  - Create unique light and color patterns or use any of the preset options.
  - Set day and time timers to activate/deactivate the string light.
  - Create groups of string lights or link them with other HUBSPACE devices.
2. Set up your voice assistant on the Intergrations tab. Choose Amazon Alexa or Google Assistant and follow the instructions to manage your devices through voice control.
- IMPORTANT:** The QR codes are unique to this string light device and will not add other devices or products to your HUBSPACE account.



DISASSEMBLY & STORAGE

1. Gently remove the plug from its electrical outlet, and carefully bind the cord which contains the plug.
  2. Beginning with the tree's top section; lift each section straight up from the section below, and continue working downward.
  3. To remove the bottom and final section; loosen the eyebolt by turning in a counter-clockwise direction and lift section "A" from the support collar of the tree stand.
  4. Gently fold the branches of each section upward, towards the center, utilizing the fabric strapping provided and position in the storage container.
- NOTE:** You may have to slightly wiggle each section as you lift each section upward.
- NOTE:** With the exception of the tree's "top" section; by holding each section upside down; the branches will collapse downward, due to the hinging, aiding in the packing of each section into the storage container.
5. Unthread the eyebolt from the tree's stand and fold together; placing in the storage container.
  6. Replace the plastic protective caps on the pole's ends before placing in carton.
  7. It is recommended to always store the tree in a cool, dry location protected from excessive exposure to heat or sunlight.
- NOTE: ALTHOUGH THE LED LIGHT STRINGS ON THE TREE ARE RATED FOR INDOOR OR OUTDOOR USE; THE COMBINATION OF THE TREE WITH THE LED LIGHTS IS FOR INDOOR USE ONLY.**

TROUBLESHOOTING

| Problem                                                  | Possible Cause                                                                                       | Solution                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|----------------------------------------------------------|------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The entire light set will not turn ON.                   | Power to the light set is OFF.                                                                       | Ensure that the power source is active, and the AC plug is properly connected.                                                                                                                                                                                                                                                                                                                                                                                |
|                                                          | There is damage to the contoller or its electrical connection.                                       | Discontinue use of the product. Call the Customer Care Service Team at 1-877-592-5233.                                                                                                                                                                                                                                                                                                                                                                        |
|                                                          | The light set is not properly connected to the controller.                                           | Ensure that the connection between the light set and the controller is tight and secure. Press the connections together, and thread the connector cap of the light set clockwise onto the controller connection.                                                                                                                                                                                                                                              |
| The circuit breaker trips when the product is turned ON. | The power wire is grounded out, or there is another electrical fault at the AC plug.                 | Discontinue use of the product. Check the wire connections. Contact a qualified electrician or call the Customer Service Team at 1-877-592-5233.                                                                                                                                                                                                                                                                                                              |
| Connecting to the HUBSPACE APP.                          | My HUBSPACE device is not connecting to Wi-Fi.                                                       | Make sure your device is connected to a power source. Your Internet connection or Wi-Fi network may be down.                                                                                                                                                                                                                                                                                                                                                  |
|                                                          | My device cannot find any Wi-Fi networks.                                                            | Make sure you have a 2.4GHz capable Wi-Fi network within range of the device you are trying to add.                                                                                                                                                                                                                                                                                                                                                           |
|                                                          | My device is in a location that does not have Wi-Fi. Can I still use it with the HUBSPACE APP?       | Yes. Use the app on a phone with an Internet connection like LTE. The phone must be within Bluetooth range of your HUBSPACE device and have Bluetooth enabled.                                                                                                                                                                                                                                                                                                |
|                                                          | A device is on another account. How do I transfer it?                                                | Scan the QR code and it will transfer to your account.                                                                                                                                                                                                                                                                                                                                                                                                        |
|                                                          | My device is offline for long periods of time.                                                       | Make sure your Wi-Fi signal strength is sufficient. You may need to move your router, use mesh Wi-Fi, or Wi-Fi extenders.                                                                                                                                                                                                                                                                                                                                     |
|                                                          | The device is on and I scanned the QR code, but the app cannot connect to it.                        | Turn off Bluetooth on your phone and turn it back on. Then, scan the QR code. If the problem persists, turn your phone off and on, then try again.                                                                                                                                                                                                                                                                                                            |
|                                                          | Can I scan the same QR code to add multiple products?                                                | No. Each product has a unique QR code.                                                                                                                                                                                                                                                                                                                                                                                                                        |
|                                                          | QR CODE is not available, missing or cannot Scan.                                                    | <ul style="list-style-type: none"><li>• Make sure the device is connected to power. Press and hold the tree's plug control button for 5 seconds (Fig 7), the lights will then pulsate, indicating it is in "Setup" mode, allowing the user to add the device.</li><li>• In the HUBSPACE app, tap +, then Add Device.</li><li>• On the Scan Device screen, tap the Search button in lower right corner.</li><li>• Follow the instructions on-screen.</li></ul> |
|                                                          | A QR code scanning issue, when attempting to add the product. QR code is damaged, inaccessible, etc. | Upon failed attempts to Scan the QR code, a 24-character code will appear below the QR Code. Enter said code and proceed.                                                                                                                                                                                                                                                                                                                                     |

This product was pre-tested before shipment and date coded. In keeping with the National Electric Code, this product is intended for seasonal (90 days max.) installation and use. For problems or questions on this product call our customer service toll-free at 1-877-592-5233.



Made in China  
Printed in China  
This is not a toy, for decorative use only.

DISTRIBUTED BY HOME DEPOT U.S.A., INC. 2455  
PACES FERRY RD., N.W. Atlanta, GA 30339 All rights reserved.