

## M2000

### Leaking out of the packing

First tighten the packing nut a half turn while moving the handle up and down a few times. If this does not completely stop the leaking, turn the packing nut another half turn while moving the handle up and down. Sometimes this may have to be repeated again and again, depending on how long the leak has gone without being fixed. Small adjustments are much better than turning the nut a full turn or more right away, as that may not be necessary. If the adjustments do not cure the leak, a new packing piece must be installed under the packing nut. There is no reason to shut off the water to do this adjustment.

## M2000

### Leaking out the nozzle

This would mean the plunger needs to be lowered. To do this, the adjusting nut above and below the pivot connector need to be raised one turn. This may need to be repeated again to completely stop the leak. Smaller adjustments are better than adjusting several turns at once, as it might not be necessary. If three or so adjustments does not fix the leak, the plunger must be replaced. Most likely it is damaged or worn excessively. To replace the plunger, a piece of tape needs to be put around the standpipe just under the hydrant head and mark the location of nozzle. Turn off the water supply and unscrew the head from the standpipe and pull out the inside rod and plunger. Replace the plunger, lubricate and install back in standpipe. Tighten head so that the head touches the tape and probably no further adjustment may be necessary. Test to make sure it is draining properly by holding your hand over the outlet nozzle right away after shutting off hydrant for a few seconds, remove hand and you should hear a sound of air rushing into the hydrant. This means it is draining properly and should be in good working order. If it is not, do the adjustment as described above.

## M2000

### Leaking out the drain hole

What you need to know here is if it is leaking in the "off" position or the "on" position. **These are two completely different adjustments.** If it is leaking when in the "on" position, the plunger may be too low and the plunger is not coming up far enough to shut off the drain hole when the hydrant is running. Making small adjustments at a time is more critical here. Move the adjustment nuts down a half turn only. By going too far you will raise the plunger so much it will not shut off when the handle is down, causing it to leak out the nozzle. Or the plunger could be worn or damaged and needs to be replaced. If the leak continues when the hydrant is in the "off" position, the plunger needs a slight adjustment down. This means raise the adjustment nuts up a half turn to make the plunger go down. Again, if two or more adjustments does not fix the problem, the plunger needs to be replaced as in above directions. The only circumstances a hydrant would need to be dug up would be damage to the valve body or standpipe due to freezing weather or aggressive soil conditions and it rusted through. No amount of adjusting will fix this and those parts would need to be replaced. **There is no other reason to ever dig up a hydrant to fix it for a leak.** It is a 100 to 1 odds that a hydrant needs to be dug up to be fixed.