


USE AND CARE GUIDE

Adjustable White A19 Dusk to Dawn Bulb



Questions, problems, missing parts? Before returning to the store,
call EcoSmart Customer Service 8 a.m. - 7 p.m., EST,
Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-800-910-7164

HOMEDEPOT.COM/ECOSMART

THANK YOU

We appreciate the trust and confidence you have placed in EcoSmart through the purchase of this bulb. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing EcoSmart!

Table of Contents

Safety Information	2	Bulb Specification.....	2
Warranty	2	Operation	3
Pre-Installation	2	Troubleshooting.....	3

Safety Information

**WARNING:** For indoor / covered outdoor use only. Do not use where directly exposed to water.

**WARNING:** This device is not intended for use with emergency exits.

**CAUTION:** Risk of Shock-Turn off power before inspection, installation, or removal. Do not open. There are no user serviceable parts inside.


Warranty


TEN-YEAR LIMITED WARRANTY

Limited Warranty: Guaranteed to last 10 years based on 3 hours use per day, 7 days per week. If this bulb does not last 10 years after date of purchase (based on 3 hours per day / 7 days per week) due to a defect in materials or workmanship, please bring the defective bulb and a receipt indicating proof of purchase to any Home Depot store. The Home Depot will provide a replacement or, at our discretion, a store credit for the value of the original purchase price. This warranty will be voided for misuse of product per the caution statement. Some states do not allow the exclusion of limitation or consequential damages, so the above exclusion may not apply to you. This warranty gives you specific legal rights and you may also have other rights that vary from state to state and province to province. Please see a store for more details.

Pre-Installation

Package Contents

A

B

Part	Description	Quantity
A	A19 LED Bulb	1
B	User Guide	1

Bulb Specification

Model	Input Volts (AC)	Input Frequency (Hz)	Input Watts (W)	Lumens (LM)	Efficacy (LM/W)	CRI
14A19060D6CCT01	120	60	9.5	800	84	90

Operation

1. Select color temperature by adjusting the switch on the bulb
 - 2700K Soft White: recommended for relaxing environments, like bedrooms. Recommended as a replacement for incandescent light bulbs.
 - 3000K Bright White: recommended as a direct replacement for halogen bulbs to match color temperature. Recommended for relaxing environments.
 - 3500K True White: appears brighter than 2700K and 3000K. Recommended for any setting.
 - 4000K: recommended as a direct replacement for fluorescent bulbs. Recommended as task lighting.
 - 5000K: Bright light that mimics daylight. Recommended for task environments, like bathrooms, kitchens, garages, etc. 5000K is also recommended for rooms that don't receive much natural light.
 - 6500K: The brightest color temperature that appears very lightly blue. Also recommended for task areas.
2. Turn off power to the fixture you are installing the bulb in.
3. Install light bulb.
4. Turn power on to light fixture.
 - The light bulb will be controlled by enclosed photocell sensor.
 - Bulb will turn on in darkness and off when light is present.
5. Power must always be supplied to the fixture for the bulb to work properly.



NOTE:

- For best performance, the bulb must not be covered or blocked from detecting light levels. If the bulb is blocked, then it may not turn on or it may be on 24/7.
- Avoid applications where bulb is blocked including: solid light fixture where housing blocks the bulb; an outside application shaded by a tree or shrub; using in a fixture with a darkened glass pane; placing fixture inside a corner or alcove where light cannot reach it.
- Dusk to dawn bulbs are not compatible with dusk to dawn fixtures or motion sensing fixtures.

Troubleshooting

Problem	Cause	Solution
Bulb will not turn off	Sensor is blocked from detecting light	□ Ensure natural light to fixture is not blocked. If the bulb is installed in a shaded area, the sensor may never receive enough light to trigger the sensor. □ Try reinstalling the bulb with the switch facing a different direction to position sensor in another direction.
Bulb will not turn on	Sensor is being blocked from detecting light or power is off	□ Ensure power is supplied to the fixture. □ Ensure fixture is not installed next to another light source that is turned on.
Bulb is intermittently blinking	Interference with sensor	□ Make light bulb does not face reflective surfaces, such as windows or shiny floors □ Avoid interference by placing Dusk to Dawn light bulbs at least 1.5ft apart from other bulbs.
Bulb is not functioning in a recessed can	Interference with sensor	□ Use in recessed cans with full trim inserts or non-reflective baffles.



Questions, problems, missing parts? Before returning to the store,
call EcoSmart Customer Service 8 a.m. - 7 p.m., EST,
Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-800-910-7164

HOMEDEPOT.COM/ECOSMART

Retain this manual for future use.